BAROSSA MOTOR INDUSTRY CO., LTD.

C O N T E N T

SPARE PARTS LIST FOR QUA250E

(OIL-COOLED & FRONT DISK BRAKE & REVERSE GEAR)

FIG 01	CYLINDER, CYLINDER HEAD	FIG 23	SEAT
FIG 02	CRANKSHAFT PISTON	FIG 24	FRONT WHEEL
FIG 03	OIL PUMP	FIG 25	FRONT BRAKE
FIG 04	CARBURETOR	FIG 26	REAR WHEEL
FIG 05	VALVE	FIG 27	TRANSMISSION STARTER
FIG 06	CAM CHAIN TENSIONER	FIG 28	REAR BRAKE
FIG 07	CRANKCASE	FIG 29	STEERING HANDEL CABLE
FIG 08	LEFT CRANKCASE COVER	FIG 30	HANDLE SWITCH
FIG 09	RIGHT CRANKCASE COVER	FIG 31	STAND FOOTREST
FIG 10	TRANSMISSION STARTER	FIG 32	GUARD
FIG 11	STARTING MOTOR	FIG 33	HEAD LIGHT
FIG 12	GEAR SHIFT	FIG 34	TAIL LIGHT
FIG 13	CLUTCH	FIG 35	WIRE HARNESS
FIG 14	EXHAUST MUFFLER	FIG 36	SPEEDOMETER
FIG 15	REAR ARM	FIG 37	WARNING
FIG 16	REAR SUSPENSION	FIG 38	CARRIER REAR
FIG 17	FRAME	FIG 39	GEAR SPEEDOMETER
FIG 18	FRONT SUSPENSION	FIG 40	OIL COOLING SET
FIG 19	STEERING	FIG 41	GEAR CASE
FIG 20	FUEL TANK	FIG 42	GEAR SHIFT
FIG 21	FRONT FENDER	FIG 43	REVERSE GEAR LEVER
FIG 22	SIDE COVER	FIG 44	NUMERICAL INDEX




FIG.01 CYLINDER,CYLINDER HEAD 气缸,气缸头

NO	PARTS NO.	PARTS NAME	Q'TY
1	11111-CBT-00	CYLINDER COMP	1
2	11121-CBT-00	HEAD COMP, CYLINDER	1
3	11141-CBT-00	COVER, CYLINDER HEAD	1
4	11144-CBT-00	AIR SEAL HEAD SIDE COVER	2
5	11151-CBT-00	GASKET, CYLINDER	1
6	11181-CBT-00	GASKET, CYLINDER HEAD	1
7	11191-CBT-00	GASKET, HEAD COVER	1
8	11196-CBT-00	RING SEAD HEAD COVER	6
9	62210-GAT-00	PLUG, SPEAK HEAD COVER	2
10	94410-10016	PIN, DOWEL 10*16	2
11	94706-06032-R	LINKED SCREW, AIR SEAL HEAD COVER	4
12	94706-06040-R	AIR SEAL HAED COVER	2
13	94717-08042-C	BOLT, STUD 8*42	4
14	95201-061005-B	NUT, HEXAGON	1
15	96414-06065-R	BOLT, FLANGE 6*65	1
16	96414-06145-B	BOLT, FLANGE 6*145	2

MENU PAGE PAGE UP PAGE DOWN INDEX




FIG.02 CRANKSHAFT.PISTON 曲軸.活塞

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	11400-CBT-00	CRANKSHAFT COMP	1
2	11631-CBT-00	PISTON	2
3	11636-CBT-00	RING SET, PISTON	2
4	13136-CBT-00	OIL PLATE, BREATHER	1
5	13178-CBT-00	OIL PUMP DRIVING WHEEL 20T	1
6	13321-CBT-00	THROUGH OIL	1
7	13324-CBT-00	SPRING, OIL THROUGH	1
8	25641-CBT-00	GEAR, PRIMARY DRIVE 19T	1
9	93110-35527	OIL SEAL TC 35*52*7	1
10	93210-30060	O-RING 3*6	1
11	93320-256217	BEARING, RADIAL BALL 6305	2
12	93510-101541	PIN, PISTON	2
13	94510-20014	PIN, DOWEL 2*13.8	1
14	94510-40004	PIN, DOWEL 4*3.7	1
15	94712-06016-B	SCREW, PAN HEAD 6*16	3
16	94717-06033-K	BOLT, ALIEN DIAMETER M7/M6*33	1
17	95201-162210-C	NUT, HEXAGON	1
18	95401-061006-C	NUT, FLANGE	1
19	96416-08032-K	BOLT, FLANGE 8*32	5
20	97050-10017	CIRCLIP, PISTON PIN	4
21	97310-162420-K	WASHER, CONICAL SPRING 16*23.9*2	1




FIG.03 OIL PUMP 機油泵

NO	PARTS NO.	PARTS NAME	Q'TY
1	13100-CBT-00	PUMP ASS'Y, OIL	1
2	13111-CBT-00	BODY, OIL PUMP	1
3	13112-CBT-00	COVER, OIL PUMP GEAR	1
4	13116-CBT-00	PLATE, OIL PUMP	1
5	13121-CBT-00	SHAFT, OIL PUMP	1
6	13124-CBT-00	GEAR, OIL PUMP	1
7	13141-CBT-00	ROTOR, OIL PUMP INNER	1
8	13142-CBT-00	ROTOR, OIL PUMP OUTER	1
9	13151-CBT-00	GASKET, OIL PUMP	1
10	13310-CBT-00	ROTOR, OIL FILTER	1
11	13311-CBT-00	CAP, OIL FILTER ROTOR	1
12	93210-30060	O-RING 3*6	1
13	94510-40007	PIN, DOWEL 4*6.5	1
14	94712-06032-B	SCREW, FLAT HEAD 6*32	3
15	96210-05020-C	BOLT, HEXAGON 5*20	2
16	96318-05010-C	SCREW, PAN HEAD 5*10	1

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.04 CARBURETOR 化油器

NO	PARTS NO.	PARTS NAME	Q'TY
1	13201-RAM-01	CARBURETOR ASS'Y	1
2	13240-RAM-01	JET, MAIN #102	2
3	13242-RAM-00	JET, SLOW #35	2
4	13276-RAM-00	HOLDER, CHOKE CABLE	2
5	13278-RAM-00	SPRING, TORSION	2
6	13555-QUA-00	INSULATOR, CARB COMP L	1
8	93210-24262	O-RING 2.4*26.2	2
9	94717-06035-B	BOLT, STUD 6*35	2
10	95401-061006-B	NUT, FLANGE	2
11	96310-06025-B	SCREW, PAN HEAD 6*20	4
12	13620-CBT-00	INSULATOR CARBURETOR	1
13	13621-CBT-00	CARB, INSULATOR GASKET	1

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.05 VALVE 閥門

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	11131-CBT-00	HOLDER, CAMSHAFT	2
2	14110-CBT-00	CAMSHAFT COMP	1
3	14150-CBT-00	SETTING SPRING, ROCKER ARM	2
4	14431-CBT-00	ARM, VALVE ROCKER	4
5	14436-CBT-00	SCREW, TAPPET ADJUSTING	4
6	14437-CBT-00	NUT, TAPPET ADJUSTING	4
7	14450-CBT-00	ROCKER ARM	2
8	14711-CBT-00	VALVE, IN	2
9	14721-CBT-00	VALVE, EX	2
10	14731-CBT-00	SEAL, VALVE STEM	4
11	14751-CBT-00	SEAL, VALVE OUTER	2
12	14761-CBT-00	SEAL, VALVE INNER	2
13	14771-CBT-00	RETAINER, VALVE SPRING	2
14	14781-CBT-00	COTTER, VALVE	4
15	93510-202813	SHEATH, CAMSHAFT	2
16	94410-10016	PIN, DOWEL 10*16	2
17	94410-10028	PIN, DOWEL 10*28	2
18	95201-081307-B	BOLT, HEXAGON	8
19	97010-20010-K	CIRCLIP 20 MM	1
20	97201-081822-B	WASHER, COPPER 8*5*18*2.2	8
21	97201-182610	SEAT, VALVE SPRING OUTER	4
22	97201-202719	WASHER, CAMSHAFT	1




FIG.06 CAM CHAIN,TENSIONER 內鏈條,張力桿

NO	PARTS NO.	PARTS NAME	Q'TY
1	14111-CBT-00	SPROCKET, CAMSHAFT	1
2	14501-CBT-00	CHAIN, CAM	1
3	14510-CBT-00	TENSIONER, CAM CHAIN	1
4	14560-CBT-00	GUIDE COMP, CAM CHAIN	1
5	90230-12008	COTTER PIN	1
6	93210-19058	O-RING 1.9*5.8	2
7	94706-07014-K	BOLT, HEXAGON 7*14	2
8	96414-06025-B	BOLT, FLANGE 6*25	2
9	97230-061312	WASHER, COPPER 6.2*13*1.2	2

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.07 CRANKCASE 曲軸箱

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	15111-CBT-00	CRANKCASE, LEFT	1
2	15127-CBT-00	CONTACT, NEITRAL SWITCH	1
3	15128-CBT-00	CLAMPER, WIRE HARNESS	1
4	15129-CBT-00	CONTACT ASS'Y, NEUTRAL SWITCH	1
5	15211-CBT-00	CRANKCASE, RIGHT	1
6	15251-CBT-00	GASKET, CRANKCASE	1
7	15276-CBT-00	HOSE	1
8	90210-15016-B	CLIP	1
9	93210-16070	O-RING 1.6*7	2
10	94410-08014	PIN, DOWEL 8*14	2
11	94410-12020	PIN, DOWEL 12*20	2
12	94717-08215-B	BOLT, STUD 8*215	8
13	96411-06012-C	BOLT, FLANGE 6*12	1
14	96411-06040-R	BOLT, FLANGE 6*40	8
15	96414-06065-B	BOLT, FLANGE 6*65	2
16	96414-12015-B	BOLT, FLANGE 12*15	1
17	97231-122118	WASHER, ALUMINUM 12.5*20.6*1.8	1
18	61920-CBT-00	CONNECTOR,OIL COOLING HOLE(NO OIL-CC	1
19	94716-12032-G	BOLT,UNION M12*32L	2
20	97231-122020	WASHER,ALUMINUM 12.3*20*2.0	4
21	15126-CBT-00	ASS'Y CONTACT, NEUTRAL SWITCH	1




FIG.08 LEFT CRANKCASE COVER 左曲軸箱蓋

NO	PARTS NO.	PARTS NAME	Q'TY
1	12655-CBT-00	CAP, A.C.G	1
2	15411-CBT-00	COVER, L CRANKCASE	1
3	15417-CBT-00	CAP, L CRANKCASE COVER	1
4	96411-06050-R	BOLT,FLANGE 6*50	1
5	15481-CBT-00	GASKET, L CRANKCASE COVER	1
6	15541-CBT-00	ENGINE OUTPUT WIRE JACKET	1
7	35550-CBT-00	FLYWHEEL COMP	1
8	35560-CBT-00	STATOR COMP	1
9	93210-24274	O-RING 2.4*27.4	1
10	93210-25138	O-RING 2.5*13.8	1
11	94410-08016	PIN, DOWEL 8*16	2
12	94716-10033-B	BOLT, CRANKSHAFT	1
13	95401-061006-B	NUT, FLANGE	1
14	96312-05028-B	SCREW, PAN HEAD WITH WASHER	3
15	96411-06065-R	BOLT, FLANGE 6*65	5
16	96411-06020-R	BOLT, FLANGE 6*20	1
17	96510-06020-B	BOLT, FLANGE 6*20	2
	ARRACHEVOLBAR ARRACHE VOLANT		

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.09 RIGHT CRANKCASE COVER 右曲軸箱蓋

MODEL:AAM-250E

NO	PARTS NO.	PARTS NAME	Q'TY
1	15221-CBT-00	GASKET, R CRANKCASE COVER	1
2	15511-CBT-00	COVER, R CRANKCASE COMP	1
3	15561-CBT-00	GAUGE ASS'Y, OIL LEVEL	1
4	15563-CBT-00	GAUGE, OIL LEVEL	1
5	25723-CBT-00	LEVER, CLUTCH	1
6	25732-CBT-00	PUSHING PLATE	1
7	25753-CBT-00	SPRING CLUTCH LEVER	1
8	25793-CBT-00	HOLDER, CLUTCH WIRE	1
9	93110-12185	OIL SEAL KC 12*18*5	1
10	93210-35178	O-RING 3.5*17.8	1
11	93310-1216100	BEARING, NEEDLE (HK-121610)	2
12	94410-08014	PIN, DOWEL 8*14	2
13	96411-06040-B	BOLT, FLANGE 6*40	7
14	96411-06050-B	BOLT, FLANGE 6*50	3

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST




FIG.10 TRANSMISSION,STARTER 傳動系統

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST

NO	PARTS NO.	PARTS NAME	Q'TY
1	25711-CBT-00	SPROCKET DRIVE 14T	1
3	26100-CBT-00	MAIN SHAFT ASS'Y	1
4	26111-CBT-00	MAIN SHAFT, TRANSMISSION 13T	1
5	26118-CBT-00	WASHER, SPLINE	3
6	26120-CBT-00	GEAR, MAIN SHAFT SECOND 18T	1
7	26130-CBT-00	GEAR, MAIN SHAFT THIRD 21T	1
8	26140-CBT-00	GEAR, MAIN SHAFT FOURTH 24T	1
9	26150-CBT-00	GEAR, MAIN SHAFT FIFTH 23T	1
10	26400-CBT-00	COUNTER SHAFT ASS'Y	1
11	26410-CBT-00	GEAR, COUNTER SHAFT LOW 37T	1
12	26411-CBT-00	COUNTER SHAFT, TRANSMISSION	1
13	26420-CBT-00	GEAR, COUNTER SHAFT SECOND 32T	1
14	26430-CBT-00	GEAR, COUNTER SHAFT THIRD 28T	1
15	26440-CBT-00	GEAR, COUNTER SHAFT FOURTH 26T	1
16	26450-CBT-00	GEAR, COUNTER SHAFT FIFTH 21T	1
17	93110-22347	OIL SEAL TC 22*34*7	1
18	93310-1521120	BEARING, NEEDLE(NK-15/12)	1
19	93310-205215	BEARING, NEEDLE 6304	1
20	93320-153511Z	BEARING, RADIAL BALL 6202Z	1
21	93320-224714B	BEARING, RADIAL 22*47*14-RS	1
23	97014-20012-K	CIRCLIP 20MM	3
24	97201-152510-K	WASHER, THRUST 15.4*24.8*1	1
25	97201-153317	WASHER, THRUST 15.2*32.8*1.7	1




FIG.11 STARTING MOTOR 起動系統

NO	PARTS NO.	PARTS NAME	Q'TY
1	15431-CBT-00	CLAPBOARD	1
2	15483-CBT-00	CLAPBOARD GASKET	1
3	23524-CBT-00	GEAR COMP, STARTING CLUTCH 38T	1
4	23570-CBT-00	STARTING CLUTCH ASS'Y	1
5	23576-CBT-00	ROLLER 10*9.5	3
6	23578-CBT-00	CAP, STARTING CLUTCH ROLER SPRING	3
7	23612-CBT-00	MOTOR DRIVE CHAIN	1
8	23632-CBT-00	PALTE, SET GEAR	1
9	23660-CBT-00	MOTOR SPROCKET WHEEL 13T	1
10	35800-CBT-00	MOTOR ASS'Y, STARTER	1
11	35831-CBT-00	CABLE, STARTER MOTOR	1
12	93110-22315	OIL SEAL SC 22*31*5	1
13	93210-18335	O-RING 1.8*33.5	1
14	96411-06012-C	BOLT, FLANGE 6*12	1
15	96411-06025-R	BOLT, FLANGE 6*25	2
16	96411-06065-R	BOLT, FLANGE 6*65	2
17	96510-06016-C	BOLT, FLANGE 6*16	3
18	97501-03029	SPRING, STARTING CLUTCH ROLLER	3
19	94510-60014	PIN,DOWEL 6*14	1

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST




FIG.12 GEAR SHIFT 變速機構

NO	PARTS NO.	PARTS NAME	Q'TY
1	24201-CBT-00	SPINDLE, GEAR SHIFT	1
2	24210-CBT-00	SPINDLE COMP, GEAR SHIFT	1
3	24220-CBT-00	DRUM, GEAR SHIFT	1
4	24223-CBT-00	POTOR, NEUTRAL SWITCH	1
5	24226-CBT-00	CAM, GEAR SHIFT	1
6	24228-CBT-00	STOPPER COMP, GEAR SHIFT	1
7	24236-CBT-00	SHAFT, GEAR SHIFT FORK	1
8	24237-CBT-00	FORK, L GEAR SHIFT	1
9	24238-CBT-00	FORK, CENTER GEAR SHIFT	1
10	24239-CBT-00	FORK, R GEAR SHIFT	1
11	93110-112410	OIL SEAL TC 11.6*24*10	1
12	94510-40013	PIN, DOWEL 4*13	4
13	96411-06020-C	BOLT, FLANGE 6*20	1
14	97201-061612-K	WASHER, THRUST 6.4*15.8*1.2	2
15	97501-05020	SPRING, GEAR SHIFT RETURN	1
16	97508-23153	SPRING, SHAFT DRUM STOPP	1
17	97510-32179	SPRING, GEAR SHIFT PLATE	1
18	24216-CBT-00	TIP POLE	1
19	94710-06014-K	SCREW	1

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST




FIG.13 CLUTCH 離合器

NO	PARTS NO.	PARTS NAME	Q'TY
1	25602-CBT-00	CLUTCH COMP	1
2	25611-CBT-00	OUTER COMP, CLUTCH	1
3	25621-CBT-00	PLATE, CLUTCH PRESSURE	1
4	25622-CHP-00	DISK, CLUTCH FRICITION	6
5	25623-CBT-00	PLATE, CLUTCH PRESSURE	6
6	25661-CBT-00	CENTER, CLUTCH	1
7	25666-CBT-00	BEARING, NEEDLE	1
8	25670-CBT-00	PLATE, CLUTCH LIFTER	1
9	25680-CBT-00	SPRING, CLUTCH	4
10	25684-CBT-00	GASKET	1
11	25686-CBT-00	WASHER	1
12	25688-CHP-00	WASHER, SPLINE	1
13	93510-202618	BEARING, SHEATH	1
14	95601-162808-K	NUT, RING	1
15	96414-06022-B	BOLT, FLANGE 6*22	4
16	97310-162720	WASHER, THRUST 16.5*26.4*2	1
17	97201-203520	WASHER, THRUST 20.2*35*2	1
	CLEEMBBAR	JEU DE CLES A CRENEAUX	
	BLOCEMBBAR	CLE BLOCAGE NOIX EMBR.	

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.14 EXHAUAT MUFFLER 排氣管

NO	PARTS NO.	PARTS NAME	Q'TY
1	31610-CBT-01	EXHAUST MUFFLER ASS'Y	1
2	31611-CBT-00	PIPE,EXHAUST	1
3	31613-CHP-00	GASKET,EXHAUST PIPE 31.5*39.5*3.5	2
4	31614-RAM-00	GASKET,MUFFLER	1
5	31617-CBT-01	MUFFLER COMP	1
6	31618-CBT-00	PROTECTOR,EXHAUST	1
7	31621-CBT-00	JOINT,EXHAUST PIPE	2
8	31623-CBT-00	COLLAR,EXHAUST PIPE JOINT	4
9	95401-081208-B	NUT,FLANGE	4
10	96316-06010-K	.SCREW,PAN HEAD	2
11	96414-08016-B	BOLT,FLANGE	1
12	96510-06020-K	BOLT,SOCKET	3
13	97210-061215	WASHER,PLATE	4
14	97301-061115-K	WASHER,SPRING 6.5*11*1.5	3

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST





FIG.15 REAR ARM 擺動臂

NO	PARTS NO.	PARTS NAME	QTY
1	32100-RAM-01	REAR ARM	1
2	32115-RAM-00	BUSH	2
3	32116-RAM-00	SPACER	1
4	32118-RAM-00	COVER,THRUST	2
5	32119-RAM-00	OIL SEAL	2
6	32160-RAM-00	SEAL,GUARD	1
7	32165-RAM-00	SUPPORT,CHAIN	1
8	32190-RAM-00	COVER	1
9	93210-25200	O-RING 2.5*20	2
10	93310-222820	BEARING,NEEDLE ROLLER HK-2220	2
11	94610-15258-B	SHAFT,PIVOT	1
12	95301-142212-B	NUT,LOCK 14MM	1
13	96414-08012-B	BOLT,FLANGE	4
14	96414-08040-B	BOLT,FLANGE	2
15	97201-142820-B	WASHER,PLATE 14.2*28.4*2.0	1
16	97201-243820	WASHER,PLATE	2

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST



NO	PARTS NO.	PARTS NAME	Q'TY
1	32210-CBT-02	SHOCK ABSORBER ASS'Y,REAR	1
2	32231-RAM-00	COVER,THRUST	2
3	90240-29025-B	PIN.COTTER 2.9*25	1
4	94610-12070-B	PIN,CLEVIS	1
5	94710-10066-B	BOLT	1
6	95311-101710-B	NUT,NYLON	1
7	97201-102220-B	WASHER.PLATE 10.5*22*2	1
8	97201-122223-B	WASHER,PLATE 12.5*22*2.3	1

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST





FIG.17 FRAME 車架

NO	PARTS NO.	PARTS NAME	Q'TY
1	32167-RAM-00	TENSIONER	2
2	32168-RAM-00	BUSH	2
3	41110-QUA-02	CADRE QUARTERBACK	1
	41110-QUA-04	CADRE SILVERHAWK	1
4	41154-RAM-00	PLUG,SPECIAL SHAPE	2
5	41181-CBT-00	ENGINE HANGER F	1
6	46412-RAM-00	BUSH,SOLID	2
7	55350-RAM-00	CLIGNOTANT AV G SILVERHAWK	1
8	55360-RAM-00	CLIGNOTANT AV D SILVERHAWK	1
9	93210-24148	O-RING 2.4*14.8	2
10	94340-06010-B	NIPPLE,GREASE M6*P1.0	1
11	94610-10113-B	BOLT,FLANGE	2
12	94610-12125-B	BOLT,FLANGE	1
13	95201-101408-B	NUT,HEXAGON	2
14	95311-121912-B	NUT,NYLON	1
15	95401-081208-B	NUT,FLANGE	2
16	95401-101409-B	NUT,FLANGE	2
17	96414-08012-B	BOLT,FLANGE	2
18	96414-10070-B	BOLT,FLANGE	2
19	97201-082420-B	WASHER,PLATE 8.7*24*2.0	2

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST

FIG 18 FRONT SUSPENSION 前懸吊系統



MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	42126-RAM-00	SHOCK ABSORBER ASS'Y	2
2	42161-QUA-01	FRT.LWR,ARM LEFT	1
3	42163-RAM-00	COLLAR	4
4	42166-QUA-00	FRT.UPPER,ARM LEFT	1
5	42171-QUA-01	FRT.LWR,ARM RIGHT	1
6	42173-AAM-00	COLLAR	2
7	42176-QUA-00	FRT.UPPER,ARM RIGHT	1
8	42183-RAM-00	COVER,THRUST	12
9	93330-152118	BUSH,SOLID	12
10	94340-06010-B	NIPPLE,GREASE M6*P1.0	6
11	94610-10208-B	SHAFT,PIVOT	2
12	95311-101710-B	NUT,NYLON	10
13	96414-10055-B	BOLT,FLANGE	4
14R	96414-10080-B	BOLT,FLANGE	2
14F	96414-10085-B	BOLT,FLANGE	2
15	97201-102020-B	WASHER,PLATE 10.5*20*2	2
16	42165-QUA-00	LOWER UNIVERSAL JOINT	2
17	97010-30015-K	CIRCLIP φ30	2
18	42161-QUA-01	FRT.LWR,ARM LEFT ASS'Y	1
19	42171-QUA-01	FRT.LWR,ARM RIGHT ASS'Y	1





FIG.19 STEERING 轉向裝置

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST

NO	PARTS NO.	PARTS NAME	Q'TY
1	42101-RAM-02	COLUMN,STEERING	1
2	42106-SK9-00	BRIDGE,TOP	1
3	42111-RAM-00	PLUG,TAPER	1
4	42118-RAM-00	BRACKER,STRG LOWER	1
5	42140-RAM-00	ROD,TIE ASS'Y	2
6	42141-RAM-00	ROD,TIE	2
7	42142-RAM-00	JOINT,UNIVERSAL 1	2
8	42143-RAM-00	JOINT,UNIVERSAL 2	2
9	42146-RAM-00	NUT	2
10	46125-RAM-00	HOLDER,HANDLE UPR	2
11	46411-RAM-00	BEARING,STEERING	2
12	46416-RAM-00	WASHER,LOCK	1
13	46417-RAM-00	OIL SEAL	2
14	90240-23020-B	PIN,COTTER 2.3*20	5
15	93510-081442-C	COLLAR	2
16	95201-101408-C	NUT,HEXAGON	2
17	95321-101710-C	NUT,CASTLE	4
18	95401-101409-B	NUT,NYLON	1
19	96210-08060-B	BOLT,HEXAGON	2
20	96414-08050-B	BOLT,FLANGE	4
21	97201-102620-B	WASHER,PLATE	1
22	97301-101720-B	WASHER,SPRING	1



BMI


FIG.20 FUEL TANK 油箱

MODEL:AAM-250E

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST


NO	PARTS NO.	PARTS NAME	Q'TY
1	43102-RAM-00	CAP ASS'Y	1
2	43103-RAM-00	CAP WASHER	1
3	43108-SK5-00	CHECK,VALVE	1
4	43110-CBT-01	FUEL TANK	1
5	43151-RAM-00	GROMMET F	2
6	43153-RAM-00	TRIM,COVER PANEL	1
7	43154-RAM-00	GUARD	1
8	43500-CBT-00	FUEL COCK ASS'Y	1
9	43535-CBT-00	JOINT THREE WAY	1
10	90210-12010	CLIP	3
11	90310-50060	HOSE,FUEL	1
12	90310-50135	HOSE,FUEL	1
13	90310-50140	HOSE,FUEL	1
14	90310-50050	HOSE 5*8*50	1
15	90310-50390	HOSE 5*8*390	2
16	93510-061015-B	COLLAR F	2
17	93510-061021-B	COLLAR R	2
18	93580-102416	GROMMET R	2
19	96318-06012-B	SCREW,PAN HEAD	2
20	96414-06025-B	BOLT,FLANGE	2
21	96414-06032-B	BOLT,FLANGE	2
22	97201-062220-B	WASHER,PLATE	4
23	97501-08140-B	SPRING,COMPRESSION	1
24	97210-061315	WASHER,PLATE	2

FIG 20 FRONT COVER



NO	PARTS NO.	PARTS NAME	Q'TY
1	51161-QUA-00	COVER,FRONT RED rouge	1
	51161-QUA-0003	COVER,FRONT YELLOW jaune	1
	51161-QUA-0004	COVER,FRONT BLUE bleu	1
	51161-QUA-0007	COVER,FRONT BLACK noir	1
2	55350-QUA-00	WINKER ASS'Y,L FRONT	1
3	55360-QUA-00	WINKER ASS'Y,R FRONT	1
4	55351-QUA-00	FLASHER COVER,FRONT L	1
5	55361-QUA-00	FLASHER COVER,FRONT R	1
6	51556-QUA-00	SYAT,FENDER LOWER	1
7	55352-QUA-00	HOLDER,FRONT WINKER WIRE	2
8	95401-061006-B	NUT,FLANGE	2
9	96112-51216-K	SCREW,TAPPING	2
10	96310-05012-B	SCREW,PAN HEAD5*12	2
11	96318-06015-B	SCREW,PAN HEAD	4
12	96112-41218-K	SCREW TAPPING	2
13	96414-06016-B	BOLT,FLANGE	2
14	97321-061825-B	WASHER,FLANGE	4
15	97201-051410-B	WASHER,PLATE5*14*1.0	2
16	56812-QUA-00	POLY STICKER(BAROSSA)	1
17	96318-06012-B	SCREW,PAN HEAD	2
18	56811-QUA-06	KIT DECO	1

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX



MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	QTY
1	13412-CBT-00	CAP,CLEANER CASE	1
2	13432-RAM-00	SEAL,ELEMENT	1
3	13433-CBT-00	PLATE,ELEMENT SET	2
4	13434-RAM-00	PLATE,JOINT	1
5	13435-RAM-00	STAY,JOINT	1
6	13451-RAM-00	ELEMENT,AIR CLEANER	1
7	13452-RAM-00	SEAL,AIR CLEANER COVER	1
8	13453-RAM-00	TUBE,AIR CLEANER JOINT	1
9	51171-QUA-00	COVER,SIDE RED rouge	1
	51171-QUA-0003	COVER, SIDE YELLOW jaune	1
	51171-QUA-0004	COVER, SIDE BLUE bleu	1
	51171-QUA-0007	COVER, SIDE BLACK noir	1
10	55722-SAF-00	REFLECTOR	2
12	90260-80047	CLAMP,HOSE	1
13	93210-35900	O-RING	1
14	95401-061006-B	NUT,FLANGE	2
15	96110-43018-K	SCREW,TAPPING	5
16	96310-05014-B	SCREW,PAN HEAD	6
17	96313-06020-K	SCREW,PAN HEAD WITH WASHER	4
18	96318-06012-B	SCREW,PAN HEAD	3
19	96318-06015-B	SCREW,PAN HEAD	8
20	97301-061215-B	WASHER,SPRING 6*11.5*1.5	2
21	97321-061825-B	WASHER,FLANGE	10
22	93580-81610	GROMMET	2
23	13437-CBT-00	GROMMET	1
24	90260-80057	CLAMP,HOSE	1
25	96110-43518-K	SCREW,TAPPING	3





FIG.23 SEAT 座墊

NO	PARTS NO.	PARTS NAME	Q'TY
1	52710-RAM-00	CATCH COMP,SEAT	1
2	52730-CBT-02	SINGLE SEAT ASS'Y-BAROSSA	1
3	95401-061006-C	NUT,FLANGE	2

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ ALL PARTS LIST


FIG 24 FRONT WHEEL 前輪



NO	PARTS NO.	PARTS NAME	Q'TY
1	42570-RAM-00	VALVE,RIM	2
2	42582-RAM-00	WHEEL,FRONT 10*5.5AT	2
3	42590-RAM-03	TIRE,FRONT AT21*7-10	2
4	95401-101409-C	NUT,FLANGE	8

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

FIG 25 FRONT BRAKE 前剎車系統




MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	42515-QUA-00	COLLAR	2
2	42581-QUA-00	HUB,FRONT	2
3	45510-QUA-00	LEFT FRONT CALIPER ASS'Y	1
4	45520-QUA-00	RIGHT FRONT CALIPER ASS'Y	1
5	45512-QUA-00	PAD,CALIPER	2
6	45533-QUA-00	THREE WAY HOSE,BRAKE	1
7	45514-QUA-00	LEFT FRONT BRAKE DISC	1
8	45515-QUA-00	RIGHT FRONT BRAKE DISC	1
11	45860-QUA-00	KNUCKLE,STEERING L ASS'Y	1
12	45865-QUA-00	KNUCKLE,STEERING R ASS'Y	1
13	90240-23020-B	PIN,COTTER 2.3*20	4
14	90240-29025-B	PIN,COTTER 2.9*25	2
15	93110-22357	OIL SEAL SD22357	2
16	93110-26427	OIL SEAL SD26427	2
17	93320-153511Z	BEARING,RADIAL BALL 6202Z	2
18	93320-204212Z	BEARING,RADIAL BALL 6004Z	2
19	93510-152210-C	COLLAR	2
20	93510-202610-C	COLLAR	2
21	94706-08017-B	BOLT,BUTTON	8
22	94710-10032-C	BOLT,STUD	8
23	94716-10022-G	BOLT,UNION	2
24	95321-101710-C	NUT,CASTLE	4
25	95321-142215-C	NUT,CASTLE	2
26	96414-06020-B	BOLT,FLANGE 6*20	1
27	96414-08020-B	BOLT,FLANGE 8*20	4
28	97201-142820-C	WASHER,PLATE 14*28*2.0	2
29	97201-213020-C	WASHER,PLATE 21*30*2.0	2
30	97230-101512	WASHER,COPPER 10.3*15*1.2	4
31	45516-QUA-00	GUARD,BRAKE DISC	2
32	96315-06016-C	SCREW	4
33	97201-102020-B	WASHER,COPPER 10*20*2.0	2


34	97201-142820-C	WASHER,PLATE 14.2x28.4x2	2

FIG 26 REAR WHEEL 後輪



NO	PARTS NO.	PARTS NAME	Q'TY
1	42570-RAM-00	VALVE,RIM	2
2	42882-RAM-00	WHEEEL,REAR 8*8.0AT	2
3	42885-RAM-00	COLLAR,WHEEL	2
4	42890-RAM-04	TIRE,REAR AT21*10-8	2
5	90240-29025-B	PIN,COTTER 2.9*25	2
6	94710-10032-C	BOLT,STUD	8
7	95326-142114-C	NUT,CASTLE FLANGE	2
8	95401-101409-C	NUT,FLANGE	8
9	97201-143240-C	WASHER,PLATE 14.2*32.5*4.0	2

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX



MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	QTY
1	25741-CBT-00	CHAIN 520H*94L	1
2	25742-RAM-00	JOINT,CHAIN	1
3	42812-QUA-02	SPROCKET,DRIVEN 39T	1
4	42821-QUA-00	COLLAR,SPROCKET AXLE	1
5	42834-QUA-00	SLIDE A	1
6	42835-QUA-00	AXLE,WHEEL	1
7	42836-QUA-00	COLLAR,AXLE WHEEL	1
8	42837-QUA-00	GEAR A 40T	1
9	42838-QUA-00	GEAR D 40T	1
10	45830-QUA-00	BRACKET,DISC	1
11	45831-RAM-00	DISC,BRAKE	1
12	93110-38558	OIL SEAL TC38558	1
13	93110-42629	OIL SEAL TC42629	1
14	93210-20320	O-RING 2*32	2
15	93310-384820N	BEARING,RADIAL BALL NK3820	1
16	93320-356214Z	BEARING,RADIAL BALL 6007Z	1
17	94706-08017-B	BOLT,BUTTON 8*17	4
18	94706-10029-B	BOLT,BUTTON 10*29	4
19	95201-325014-C	NUT,HEXAGON	4
20	95301-101410-B	NUT,LOCK	4
21	97010-38018-K	CIRCLIP φ38	3
22	97201-384720-K	WASHER,PLATE 38*47*2.0	3




FIG.28 REAR BRAKE 後剎車系統

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	32355-CBT-00	LEVER,CAMSHAFT	1
2	45801-QUA-00	PARKING BRAKE CALIPER ASS'Y	1
3	45810-QUA-00	BRACKET,CALIPER	1
4	45815-QUA-00	PAD,CALIPER	1
7	45871-RAM-00	RESERVOIR	1
8	45874-RAM-00	HOSE 8*13*400	1
9	45877-RAM-00	CYLINDER KIT,MASTER	1
10	45878-NAF-00	DIAPHRAGM,RESERVOIR	1
11	45879-NAF-00	CAP,RESERVOIR	1
12	61320-RAM-00	HOSE,BRAKE	1
13	90220-80013	CLAMP	2
14	90230-12008	COTTER PIN	2
15	94610-06016-B	PIN,CLEVIS	1
17	94712-04040-K	SCREW,FLAT HEAD	2
18	94716-10022-G	BOLT,UNION	1
19	96414-06016-B	BOLT,FLANGE	1
20	96414-06022-B	BOLT,FLANGE	2
21	96414-08020-B	BOLT,FLANGE	4
22	97230-101512	WASHER,COPPER 10.3*15*1.2	5
23	97508-20200-B	SPRING TORSION	1
24	95401-081208-B	NUT,FLANGE	1
25	97301-081420-B	WASHER,SPRING	2
26	96414-10028-B	BOLT,FLANGE	2
27	94716-10033-G	BOLT,UNION	1




FIG.29 STEERING HANDLE CABLE 轉向把手,鋼索

NO	PARTS NO.	PARTS NAME	Q'TY
1	46110-RAM-01	HANDLEBAR	1
2	46240-RAM-00	GRIP	2
3	61813-QUA-00	CABLE,PARKING RAKE	1
5	61420-CBT-00	CABLE,CLUTCH	1
6	61620-STG-00	CABLE,THROTTLE	1
7	61720-RAM-00	CABLE,CHOKE	1

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.30 HANDLE SWITCH , LEVER 把手開關,拉桿

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	45872-RAM-00	LEVER,R	1
2	45890-RAM-00	WIRING,FR STOP SWITCH	1
3	56270-ROA-00	MIRROR ASS'Y,BACK	1
4	62910-RAM-01	LEVER ASS'Y,HANDLEL	1
5	62912-SK9-01	LEVER,L	1
6	62916-RAM-00	BOLT,WIRE ADJUSTING	3
7	62917-RAM-00	NUT,WIRE ADJUSTING	3
8	62920-RAM-01	THROTTLE LEVER ASS'Y	1
9	62923-RAM-00	CAP,THROTTLE	1
10	62924-RAM-00	GASKET,THROTTLE	1
11	62925-RAM-00	THROTTLE LEVER	1
12	62926-RAM-00	JOINT,CABLE	1
13	62927-RAM-00	ARM,THROTTLE	1
14	62928-RAM-00	LEVER,THROTTLE	1
15	62930-RAM-02	HANDLE SWITCH ASS'Y L	1
16	62971-RAM-00	PIN,LOCK	1
17	62973-RAM-00	LOCK,LEVER	1
18	62976-RAM-00	COVER	1
19	93560-68507	COLLAR,LEVER 6.3*8.5*7.4	1
20	94710-05022-G	BOLT,LEVER	1
21	94710-06029-G	BOLT,LEVER	1
22	94714-06016-G	BOLT	1
23	94714-08012-G	BOLT	1
24	95201-050804-G	NUT,HEXAGON	1
25	95311-050805-K	NUT,NYLON	1
26	95311-061006-K	NUT,NYLON	1
27	96310-03008-B	SCREW,PAN HEAD	1
28	96310-04015-G	SCREW,PAN HEAD	2
29	96310-05015-G	SCREW,PAN HEAD	1
30	96310-05030-G	SCREW,PAN HEAD	1
31	96310-05040-G	SCREW,PAN HEAD	1
32	96310-06010-G	SCREW,PAN HEAD	1
33	96510-06020-G	BOLT	2
34	97201-051516-C	WASHER,PLATE 5.3*15*1.6	1




FIG.30 HANDLE SWITCH , LEVER 把手開關,拉桿

NO	PARTS NO.	PARTS NAME	Q'TY
34	97201-051516-C	WASHER,PLATE 5.3*15*1.6	1
35	97201-061310-B	WASHER,PLATE 6.5*13*1.0	1
36	97201-142016-C	WASHER,PLATE 14.2*19.7*1.6	1
37	97501-08025-B	SPRING	1
38	97508-10240-B	SPRING	1
39	96414-08012-K	BOLT,FLANGE	1




FIG.31 STAND FOOTREST 腳踏桿

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	53210-RAM-00	CHANGER PENDAL ASS'Y	1
2	53211-RAM-00	CHANGER PENDAL	1
3	53214-ROA-00	RUBBER,CHANGE PEDAL	1
4	53231-RAM-00	FOOTREST L	1
5	53233-RAM-00	MUDGUARD STAY L1	1
6	53234-RAM-00	MUDGUARD L	1
7	53236-QUA-00	MUDGUARD STAY L2	1
8	53241-RAM-01	FOOTREST R	1
9	53243-RAM-00	MUDGUARD STAY R1	1
10	53244-RAM-00	MUDGUARD R	1
11	53246-QUA-00	MUDGUARD STAY R2	1
12	53261-CBT-00	PEDAL,BRAKE	1
13	94714-06020-B	BOLT,FLANGE	1
14	95401-061006-B	NUT,FLANGE	1
15	96318-06012-B	SCREW,PAN HEAD	6
16	96318-06015-B	SCREW,PAN HEAD	8
17	96414-10025-B	BOLT,FLANGE	4
18	97011-12010-B	CIRCLIP 12*1.0	1
19	97201-152620-B	WASHER,PLATE 15.2*25.6*2.0	1
20	97506-12140-B	SPRING,TENSION	1
21	97506-14050-B	SPRING,TENSION	1
22	97201-122223-B	WASHER,PLATE 12.2*22*2.3	2




FIG.32 GUARD 護板

NO	PARTS NO.	PARTS NAME	Q'TY
1	41601-QUA-01	SHIELD,FRONT	1
2	52850-RAM-04	SHIELD,REAR	1
3	55750-RAM-00	WINKER ASS'Y,L REAR	1
4	55760-RAM-00	WINKER ASS'Y,R REAR	1
5	95201-101408-B	NUT,HEXAGON	2
6	96414-08016-B	BOLT,FLANGE	7

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.33 HEADLIGHT 前燈

NO	PARTS NO.	PARTS NAME	Q'TY
1	55300-STG-00	HEAD LIGHT ASS'Y	1
2	55314-NFF-00	BULB,HEAD LIGHT 12V30/30W	1
3	55315-AL9-00	STAY,HEAD LIGHT	1
4	**55316-NGF-00**	**BULB,POSITION LAMP**	1
5	55320-STG-00	LENS ASS'Y	1
6	55340-STG-01	SOCKET CORD ASS'Y	1
7	95101-05012	NUT,SPRING	1
8	96112-51616-K	SCREW,TAPPING	1
9	96310-04010-B	SCREW,PAN HEAD	1
10	97201-051410-B	WASHER,PLATE 5*14*1.0	1

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.34 TAIL LIGHT 後燈

NO	PARTS NO.	PARTS NAME	Q'TY
1	55700-CHP-00	TAIL LIGHT ASS'Y	1
2	55701-CHP-00	STAND,TAIL LIGHT	1
3	55713-PAF-00	BULB STAND,TAIL LIGHT	1
4	55714-PAF-00	BULB, TAIL LIGHT	1
5	55715-PAF-00	WASHER	1
6	55721-PAF-00	LENS,TAIL LIGHT	1
7	55726-RAM-00	HOLDER,TAIL LIGHT	1
8	55743-PAF-00	LENS,LICENSE LIGHT	1
9	93510-061010	COLLAR	4
10	93580-102212	GROMMET	4
11	95401-061006-B	NUT,FLANGE	2
12	96112-43818-B	SCREW,TAPPING	2
13	96414-06020-B	BOLT,FLANGE	2
14	97201-061820-B	WASHER,PLATE	4

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.35 WIRE HARNESS 主電線配線

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	55550-RAM-00	NEUTRAL LIGHT ASS'Y	1
2	56120-CBT-00	SCREW DRIVER	1
3	56140-CBT-00	TOOL PLUG	1
4	56190-RAM-00	GAUGE,AIR	1
5	61120-CBT-02	WIRE,HARNESS	1
6	61151-CHP-00	FUSE (15A250V)	1
7	62100-CHP-00	BATTERY ASS'Y (YTX9A-BS)	1
8	62110-CBT-00	CABLE,BATTERY	1
9	62120-RAM-00	CABLE,EARTH	1
10	62310-CBT-00	IGNITION COIL ASS'Y	2
11	62350-NAF-01	FLASHER RELAY ASSEMBLY	1
12	62360-CBT-00	RECTIFIER&REGULATOR COMP	1
13	62370-NAF-00	HORN	1
14	62500-RAM-00	KEY SET	1
15	62501-RAM-00	MAIN SWITCH ASS'Y	1
16	62503-RAM-00	LOCK COMP,STEERING HANDLE	1
17	62540-QUA-00	C.D.I UNIT ASS'Y	1
18	62550-CBT-00	STARTER RELAY SWITCH COMP	1
19	62980-CHP-00	SWITCH ASS'Y,REAR STOP	1
20	95401-061006-C	NUT,FLANGE	1
21	96310-05012-B	SCREW,PAN HEAD5*12	2
22	96312-06016-K	SCREW,PAN HEAD WITH WASHER	2
23	96414-06012-B	BOLT,FLANGE	1




FIG.36 SPEEDOMETER 速度表

NO	PARTS NO.	PARTS NAME	Q'TY
1	55510-RAM-01	SPEEDOMETER ASS'Y	1
2	55516-RAM-01	HOLDER,SPEEDOMETER	1
3	61520-RAM-01	CABLE,SPEEDOMETER ASS'Y	1
4	93510-050814-B	COLLAR,SPEEDOMETER	2
5	93580-81615	GROMMET	2
6	95401-050805-B	NUT,FLANGE	2
7	96414-06020-B	BOLT,FLANGE 6*20	1
8	97201-051610	WASHER,PLATE 5.3*16*1	2

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.37 警告標示

NO	PARTS NO.	PARTS NAME	Q'TY
1	56576-AAM-01	LABEL WARNING 3 (Tire)	1
2	56578-AAM-00E	LABEL WARNING 2 (Age)	1
3	56781-AAM-01	LABEL WARNING 1 (Operation)	1
4	94320-32096	RIVET 3.2*9.6	14

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.38 CARRIER,REAR 後架

NO	PARTS NO.	PARTS NAME	Q'TY
1	52850-RAM-03	CARRIER,REAR	1
2	55750-RAM-00	WINKER ASS'Y,L REAR	1
3	55760-RAM-00	WINKER ASS'Y,R REAR	1
4	95201-101408-B	NUT,HEXAGON	2
5	96414-08016-B	BOLT,FLANGE	4

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.39 GEAR,SPEEDOMETER 速度表齿轮

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	15421-CBT-01	COVER,L REAR CRANKCASE	1
2	25711-CBT-00	SPROCKET DRIVE(12T)	1
3	25716-RAM-00	PLATE,FIXING	1
4	42563-GOO-00	GEAR,SPEEDOMETER BODY	1
5	45835-CBT-00	non détaillé	1
6	45838-RAM-00	non détaillé	1
7	45849-CBT-00	non détaillé	1
8	93110-06114	OIL SEAL VC 6*11*4	1
9	93210-20190	O-RING 2.0*19	1
10	93320-103009U	BEARING,RADIAL BALL 6200LUCS05/2A	1
11	93510-101706-B	COLLAR	1
12	94510-30018	PIN,DOWEL 3*18	1
13	96210-06010-B	BOLT,HEXAGON 6*10	2
14	96411-06020-B	BOLT,FLANGE 6*20	2
15	96414-06025-B	BOLT,FLANGE 6*25	1
16	97010-10010-K	CIRCLIP STW-10	1
17	97012-30012-K	CIRCLIP RTW-30	1
18	97201-101805	WASHER,PLATE 10.5*18*0.5	1
19	42560-AAM-00	GEAR,SPEEDOMETER ASS'Y	1
20	45834-CBT-00	GEAR DRIVE ASS'Y	1




FIG.40 OIL COOLING SET 機油冷卻裝置

NO	PARTS NO.	PARTS NAME	Q'TY
1	61900-CBT-00	OIL COOLING TANK	1
2	61903-CBT-00	LWR HOLDER,OIL COOLING TANK	1
3	61904-CBT-00	OIL COOLING TANK COVER	1
4	61910-CBT-00	TUBE,OIL COOLING TANK (405MM)	1
5	61911-CBT-00	TUBE,OIL COOLING TANK (420MM)	1
6	94716-12032-G	BOLT,UNION M12*32L	2
7	97231-122020	WASHER,ALUMINUM 12.3*20*2.0	8
8	96414-06012-B	BOLT,FLANGE 6*12	2

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX




FIG.41 GEAR CASE 齒輪箱

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	15163-QUA-00	BOLT,FLANGE 12*13	1
2	42831-QUA-00	LEFT GEAR CASE	1
3	42832-QUA-00	RIGHT GEAR CASE	1
4	42833-QUA-00	GASKET,GEAR CASE	1
5	42855-QUA-00	ROCKER ARM,REVERSE GEAR SHIFT	1
6	93110-12227	OIL SEAL TC12227	1
7	93110-38558	OIL SEAL TC38558	1
8	93110-42629	OIL SEAL TC42629	1
9	93110-62729	OIL SEAL TC62729	1
10	93310-142012	BEARING,RADIAL BALL HK1412	1
11	93310-556825N	BEARING,RADIAL BALL NK5525	1
12	93320-123712A	BEARING,RADIAL BALL 6301A	1
13	93320-356214Z	BEARING,RADIAL BALL 6007Z	1
14	94410-10014	PIN,DOWEL 10*14	2
15	94717-08042-C	BOLT,STUD 8*42	1
16	95201-081207-B	NUT,HEXAGON	1
17	96414-08038-B	BOLT,FLANGE 8*38	5
18	96414-08035-B	BOLT,FLANGE 8*35	2
19	96414-08012-B	BOLT,FLANGE 8*12	1
20	96414-06010-B	BOLT,FLANGE 6*10	1
21	97012-62020-K	CIRCLIP φ62	1
22	97230-122011	WASHER,COPPET 12*22*1.1	1
23	97230-081512	WASHER,COPPET 8*15*1.2	1




FIG.42 GEAR SHIFT 變速機構

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX

NO	PARTS NO.	PARTS NAME	Q'TY
1	42841-QUA-00	COUNTER SHAFT,TRANSMISSION	1
2	42842-QUA-00	SLIDE B	1
3	42843-QUA-00	GEAR B1 17T	1
4	42844-QUA-00	GEAR B2 17T	1
5	42845-QUA-00	FORK,GEAR SHIFT	1
6	42851-QUA-00	DRUM,REVERSE GEAR SHIFT	1
7	42852-QUA-00	GEAR C 24T	1
8	42853-QUA-00	GEAR B3 17T	1
9	42854-QUA-00	SPRING,RETURN	1
10	93310-151913K	BEARING,RADIAL BALL K151913	1
11	93310-151917K	BEARING,RADIAL BALL K151917	1
12	93310-202413K	BEARING,RADIAL BALL K202413	1
13	97010-12010-K	CIRCLIP φ12	1
14	97010-20012-K	CIRCLIP φ20	1
15	97011-10010-K	CIRCLIP φ10	1
16	97014-15010-K	CIRCLIP φ15	1
17	97201-122210	WASHER,PLATE 12*22*1.0	1
18	97201-151910-K	WASHER,PLATE 15*19*1.0	1
19	97201-151914-K	WASHER,PLATE 15*19*1.4	1
20	97201-152110-K	WASHER,PLATE 15*21*1.0	2
21	97201-152510-K	WASHER,PLATE 15*25*1.0	2
22	97201-202610-K	WASEHR,PLATE 20*26*1.0	2




FIG.43 REVERSE GEAR LEVER 手動排檔系統

NO	PARTS NO.	PARTS NAME	Q'TY
1	42856-QUA-00	PLATE,REVERSE GEAR REAR CABLE	1
2	42861-QUA-00	HOLDER SUPPORTING BRACKET	1
3	42862-QUA-00	REVERSE GEAR LEVER	1
4	42863-QUA-00	HOLDER, REVERSE GEAR LEVER	1
5	42864-QUA-00	SPRING,RETURN	1
6	42865-QUA-00	PIN,LEVER FIXTURE	1
7	42866-QUA-00	GEAR TURNING AXLE	1
8	42868-QUA-00	COVER,REVERSE GEAR LEVER	1
9	42869-QUA-00	LEVER HANDLE ASS'Y	1
10	61210-QUA-00	CABLE,GEAR SHIFT	1
11	90240-18016-B	PIN,COTTER 1.8*16	1
12	95401-061006-B	NUT,FLANGE	1
13	96210-06012-B	BOLT,HEXAGON 6*12	2
14	96310-05014-B	SCREW,PAN HEAD 5*14	1
15	96414-06014-B	BOLT,FLANGE 6*14	1
16	96414-08012-B	BOLT,FLANGE 8*12	2
17	96414-08016-B	BOLT,FLANGE 8*16	2
18	97201-081610-B	WASHER,PLATE 8*16*1.0	2
19	97201-102020-B	WASHER,PLATE 10*20*2.0	1

MENU PAGE PAGE UP ▲ PAGE DOWN ▼ INDEX