

DIAMO® Scout

PARTS CATALOG

Second Edition August 2008



The information and diagrams included in this catalog are the exclusive property of LS MotorSports, LLC and may not be reproduced in any media without the express written consent of LS MotorSports, LLC.

For more information contact:

LS MotorSports, LLC
10215 S Sam Houston Parkway W
Houston, TX 77071
281-277-6140

*Information contained in this publication is subject to change without notice.
For the most up to date information please contact DIAMO USA or an Authorized Dealer*



www.DIAMOUSA.com

Copyright © 2004-2008 LS MotorSports, LLC. Reproduction without written permission is completely forbidden.

CONTENTS

PAGE	TITLE
4	DOCUMENTS
5	CYLINDER
6	CRANKSHAFT
7	VALVE
8	CAMSHAFT CHAIN
9	WATER PUMP
10	RADIATOR
11	OIL PUMP
12	AIR CLEANER
13	CARBURETOR
14	EXHAUST
15	CRANKCASE
16	LEFT AND RIGHT COVER
17	STARTER CLUTCH
18	CLUTCH
19	GENERATOR
20	STARTER MOTOR
21	ENGINE MOUNT
22	FRONT DIFFERENTIAL
23	FRONT DIFFERENTIAL, CONT.
24	FRONT AXLE
25	2WD / 4WD SHIFT LINKAGE
26	FOC
27	HANDLEBAR
28	FUEL TANK
29	REAR FENDER / SEAT


CONTENTS CONT.

30	FRONT FENDER
31	FRONT A-ARM
32	SWINGARM ASSY
33	FRONT WHEEL
34	REAR SHOCK ABSORBER / AXLE
35	REAR WHEEL
36	REAR DIFFERENTIAL
37	TRANSMISSION
38	TRANSMISSION, CONT
39	SUPPORT BRACKET, TRANSMISSION
40	SHIFT ROD
41	SHOCK ABSORBER, FRONT
42	STEERING COLUMN
43	ELECTRICAL
44	BRAKE SYSTEM
45	BRAKE SYSTEM, CONT.
46	BUMPER AND RACK

Fig. 00 **Documents**


Ref	Code	Part Number	Description	
1		06-034-0001	Owners Manual	
2		06-034-0002	Parts Manual CD	
3		06-034-0003	Service Manual	

Fig. 01 Cylinder




Ref	Code	Part Number	Description	Qty
1	22401b	06-034-0101	CYLINDER HEAD ASSY	1
2	22402	06-034-0102	GUIDE, VALVE	2
3	10112	06-034-0103	CIRCLIP 12	2
4	10128	06-034-0104	BOLT M6X12	1
5	22405	06-034-0105	GASKET 6	1
6	10014	06-034-0106	BOLT STUD M8X25	2
7	22407	06-034-0107	BREATHER ASSY	1
8	22408	06-034-0108	O-RING 95X3.3	1
9	10008	06-034-0109	BOLT SOCKET HEAD M6X20	2
10	22410	06-034-0110	VALVE COVER INTAKE SIDE	1
11	22411	06-034-0111	VALVE COVER EXHAUST SIDE	1
12	22412	06-034-0112	O-RING 57.5X2.3	2
13	10008	06-034-0113	BOLT SOCKET HEAD M6X20	5
14	22414	06-034-0114	NUT CROWN M8	4
15	22415	06-034-0115	WASHER PLATE 8	4
16	22416a	06-034-0116	GASKET, CYLINDER HEAD	1
17	22417	06-034-0117	PIN DOWEL 14X16	2
18	22418	06-034-0118	BOLT FLANGE M6X120	2
19	22419	06-034-0119	PLUG SPARK(NGK DR8EA)	1
20	22420a	06-034-0120	CYLINDER	1
21	22421	06-034-0121	GASKET, CYLINDER	1
22	22422	06-034-0122	PIN DOWEL 10X14	2
23	22423	06-034-0123	PIPE BREATHER1	1
24	22424	06-034-0124	CLIP 12MM	2

Fig. 02 Crankshaft




Ref	Code	Part Number	Description	Qty
1	22501	06-034-0201	CRANKSHAFT ASSY	1
2	22502	06-034-0202	NUT M16X1	1
3	22503	06-034-0203	WASHER PLATE 16	1
4	22504	06-034-0204	KEY WOODRUFF	1
5	22505a	06-034-0205	PISTON	1
6	22506a	06-034-0206	PISTON RING SET	1
7	22507	06-034-0207	PISTON PIN	1
8	22508	06-034-0208	CLIP	2

Fig. 03 Valve




Ref	Code	Part Number	Description	Qty
1	22601	06-034-0301	INTAKE VALVE	1
2	22602	06-034-0302	EXHAUST VALVE	1
3	22603	06-034-0303	SEAT, VALVE SPRING	2
4	22604	06-034-0304	INNER VALVE SPRING	2
5	22605	06-034-0305	OUTER VALVE SPRING	2
6	22606	06-034-0306	SEAL, VALVE STEM	2
7	22607	06-034-0307	RETAINER, VALVE SPRING	2
8	22608	06-034-0308	COTTER, VALVE	4
9	22609	06-034-0309	ROCKER ARM, VALVE	2
10	22610	06-034-0310	EXHAUST ROCKER SHAFT	1
11	22611	06-034-0311	INTAKE ROCKER SHAFT	1
12	22612	06-034-0312	O-RING 9X2	1
13	22613	06-034-0313	ADJUSTING SCREW, VALVE	2
14	22614	06-034-0314	NUT M6X0.75	2

Fig, 04 Camshaft Chain




Ref	Code	Part Number	Description	Qty
1	22701	06-034-0401	CAMSHAFT ASSY	1
2	10012	06-034-0402	BEARING	1
3	10013	06-034-0403	BEARING-B6202Z	1
4	22704	06-034-0404	PLATE	1
5	10128	06-034-0405	BOLT M6X12	2
6	22706	06-034-0406	LOCK WASHER	1
7	22707	06-034-0407	CAM CHAIN SPROCKET	1
8	10024	06-034-0408	DOWEL PIN B4X10	1
9	10025	06-034-0409	BOLT M10X1.25X25	1
10	22710	06-034-0410	WASHER PLATE 10	1
11	22711	06-034-0411	BREATHER PLATE2	1
12	22712	06-034-0412	CHAIN	1
13	22713	06-034-0413	GUIDE STOPPER1	1
14	22714	06-034-0414	GUIDE STOPPER2	1
15	22715	06-034-0415	CAM CHAIN TENSIONER ASSY	1
16	22716	06-034-0416	GASKET TENSIONER CASE	1
17	10036	06-034-0417	SOCKET HEAD BOLT M6X14	2
18	22718	06-034-0418	CHAIN TENSIONER PIVOT BOLT	1
19	22719	06-034-0419	O-RING 14.5X1.8	1
20	22720	06-034-0420	CAMSHAFT	1

Fig. 05 Water Pump




Ref	Code	Part Number	Description	Qty
1	22801	06-034-0501	IMPELLER SHAFT ASSY	1
2	22802	06-034-0502	HOUSING COVER	1
3	22803	06-034-0503	GASKET, HOUSING COVER	1
4	10041	06-034-0504	SOCKET HEAD BOLT M6X35	3
5	10043	06-034-0505	BEARING	1
6	22806	06-034-0506	WATER PUMP HOUSING	1
7	22807	06-034-0507	OIL SEAL 10X21X5	1
8	22808	06-034-0508	MECHANICAL SEAL	1
9	10044	06-034-0509	CIRCLIP 10	1
10	22810	06-034-0510	GASKET 6	1
11	10049	06-034-0511	O-RING 33.5X2.65	1
12	22812	06-034-0512	SHAFT	1
13	10070	06-034-0513	DOWEL PIN C3X22	1
14	22814	06-034-0514	WASHER PLATE 8	2
15	22815	06-034-0515	IMPELLER SHAFT GEAR	1
16	10072	06-034-0516	CIRCLIP 8	1
17	22817	06-034-0517	JOINT	1
18	10082	06-034-0518	O-RING 15.5X2.5	2
19	10083	06-034-0519	SOCKET HEAD BOLT M6X15	2
20	22820	06-034-0520	WATER PUMP ASSY	1

Fig. 06 Radiator




Ref	Code	Part Number	Description	Qty
1	22901	06-034-0601	THERMOSTAT	1
2	22902	06-034-0602	THERMOSTAT COVER	1
3	10085	06-034-0603	SOCKET HEAD BOLT M6X25	2
4	22904T	06-034-0604	RADIATOR ASSY	1
5	22905T	06-034-0605	BLOWER ASSY	2
6	10087	06-034-0606	FLANGE BOLT M6X9	6
7	22907a	06-034-0607	SAFETY VALVE	1
8	23028	06-034-0608	PIPE 2	1
9	22909T	06-034-0609	RADIATOR FILLER HOSE	1
10	22910T	06-034-0610	RETURN HOSE	1
11	22911	06-034-0611	FEED HOSE	1
12	22912	06-034-0612	COMPRESSION SPRING	2
13	22913	06-034-0613	HOSE CLAMP1	6
14	22914	06-034-0614	HOSE CLAMP2	2
15	22915	06-034-0615	HOSE1	1
16	10110	06-034-0616	BOLT M6X20	2
17	22917	06-034-0617	RADIATOR SIDE SUPT GROMMET	2
18	22918	06-034-0618	COLLAR	2
19	22919	06-034-0619	THERMOSTAT SWITCH ASSY	1
20	10004	06-034-0620	NUT M6	2
21	10019	06-034-0621	WASHER PLATE 10	2
22	10094	06-034-0622	CLIP 2X20	2
23	22923	06-034-0623	PIPE 1	1
24	22924	06-034-0624	CLIP	2
25	22925	06-034-0625	TANK RECOVERY	1
26	22926	06-034-0626	CAP	1
27	10140	06-034-0627	BOLT FLANGE M6X12	1

Fig. 07 Oil Pump




Ref	Code	Part Number	Description	Qty
1	23101	06-034-0701	OIL PUMP ASSY	1
2	10096	06-034-0702	DOWEL PIN 3X12	2
3	23103	06-034-0703	GEAR PUMP DRIVEN	1
4	10097	06-034-0704	DOWEL PIN C3X22	1
5	22814	06-034-0705	WASHER PLATE	1
6	10130	06-034-0706	CIRCLIP	1
7	23107	06-034-0707	GASKET	1
8	10098	06-034-0708	SCREW M6X25	2
9	23109	06-034-0709	OIL STRAINER	1
10	23110	06-034-0710	COMPRESSION SPRING	1
11	23111	06-034-0711	DRAIN PLUG	1
12	23112	06-034-0712	O-RING 36X3.5	1

Fig. 08 Air Cleaner




Ref	Code	Part Number	Description	Qty
1	23201	06-034-0801	INTAKE MANIFOLD 1	1
1A	23202a	06-034-0801A	INTAKE MANIFOLD 2	2
2	23202	06-034-0802	O-RING 35X2	2
3	10085	06-034-0803	SOCKET HEAD BOLT M6X25	2
4	23204	06-034-0804	BASE PLATE, INTAKE	1
5	23205	06-034-0805	HOSE CLAMP D	1
6	23206	06-034-0806	HOSE CLAMP C	1
7	23207	06-034-0807	AIR CLEANER HOSE	1
8	23208	06-034-0808	HOSE CLAMP B	1
9	23209	06-034-0809	HOSE CLAMP A	1
10	23210	06-034-0810	COVER AIR CLEANER	1
11	23211	06-034-0811	AIR CLEANER CASE1	1
12	23212	06-034-0812	AIR FILTER ELEMENT	1
13	23213	06-034-0813	ELEMENT COVER	1
14	23214	06-034-0814	CLAMP	2
15	23215	06-034-0815	HOSE	1
16	23216	06-034-0816	PLUG	1
17	23217	06-034-0817	AIR CLEANER ASSY	1
18	23218	06-034-0818	AIR CLEANER COVER CLIP	6

Fig. 09 Carburetor




Ref	Code	Part Number	Description	Qty
1	23301	06-034-0901	CARBURETOR ASSY	1
1A	23301a	06-034-0901A	CARBURETOR ASSY	1
2	23302	06-034-0902	JET NEEDLE SET	1
3	23303	06-034-0903	AUTO CHOKE ASSEM	1
4	23304	06-034-0904	FLOAT ASSY	1
5	23305	06-034-0905	BOWL GASKET	1
6	23306	06-034-0906	MAIN JET	1
		06-034-0907	IDLE JET	
7	30235	06-034-0908	FUEL HOSE COUPLER	1
8	23308	06-034-0909	HOSE $\Phi 8 \times 4.5 \times 260$	1
9	23309	06-034-0910	HOSE $\Phi 8 \times 4.5 \times 390$	1
10	23310	06-034-0911	HOSE $\Phi 8 \times 4.5 \times 280$	1

Fig. 10 Exhaust




Ref	Code	Part Number	Description	Qty
1	23433	06-034-1001	EXHAUST PIPE 1	1
2	10099	06-034-1002	NUT M8	2
3	23403	06-034-1003	EXHAUST PIPE GASKET	3
4	10106	06-034-1004	WASHER 8	2
5	10117	06-034-1005	WASHER PLATE 10	1
6	10120	06-034-1006	BOLT FLANGE M10X1.25X62	1
7	23418	06-034-1007	SPRING	2
8	23408	06-034-1008	SPRING	1
9	10099	06-034-1009	NUT M8	2
10	23410	06-034-1010	MUFFLER SUPPORT BOTTOM	1
11	23411	06-034-1011	MUFFLER JOINT	1
12	23412	06-034-1012	MUFFLER	1
13	10015	06-034-1013	NUT M10X1.25	1
14	10117	06-034-1014	WASHER PLATE 10	1
15	23415	06-034-1015	MUFFLER SUPPORT	1
16	23434	06-034-1016	EXHAUST PIPE 2	1
17	23435	06-034-1017	EXHAUST PIPE 3	1

Fig. 11 Crankcase




Ref	Code	Part Number	Description	Qty
1	23501	06-034-1101	CRANKCASE ASSY	1
2	23502	06-034-1102	HOLDER	2
3	23503	06-034-1103	COLLAR	2
4	23504	06-034-1104	O-RING	4
5	23505	06-034-1105	WASHER PLATE 16	2
6	10121	06-034-1106	CIRCLIP 16	2
7	22422	06-034-1107	DOWEL PIN 10X14	2
8	23508	06-034-1108	FLANGE BOLT M6X70	4
9	23509	06-034-1109	FLANGE BOLT M6X100	5
10	23510	06-034-1110	OIL SEAL 30X45X5	1
11	23511	06-034-1111	STUD BOLT M8X245	4
12	23512	06-034-1112	COVER CRANKCASE RIGHT	1
13	10036	06-034-1113	SOCKET HEAD BOLT M6X14	2
14	23514	06-034-1114	LEFT CRANKCASE	1
15	23515	06-034-1115	SEAL	1

Fig. 12 Left and Right Cover




Ref	Code	Part Number	Description	Qty
1	23601	06-034-1201	LEFT CRANKCASE COVER	1
2	23602	06-034-1202	FLANGE BOLT M6X52	10
3	23603	06-034-1203	HOSE CLAMP B	1
4	23604	06-034-1204	JOINT A	1
5	23605	06-034-1205	AIR STRAINER B	1
6	23606	06-034-1206	AIR STRAINER A	1
7	23607	06-034-1207	JOINT B	1
8	23608	06-034-1208	HOSE CLAMP A	1
9	23609	06-034-1209	OIL SEAL	1
10	22422	06-034-1210	DOWEL PIN 10X14	4
11	23611	06-034-1211	DIPSTICK	1
12	10122	06-034-1212	O-RING 18X2.65	1
13	23613	06-034-1213	OIL PLUG	1
14	10123	06-034-1214	O-RING 14X2.65	1
15	23615	06-034-1215	FLANGE BOLT M6X40	10
16	23616	06-034-1216	RIGHT CRANKCASE COVER	1
17	23617	06-034-1217	GASKET, RGT COVER	1
18	23618	06-034-1218	GASKET, LFT COVER	1

Fig. 12 Starter Clutch




Ref	Code	Part Number	Description	Qty
1	23701	06-034-1201	IDLER GEAR	1
2	23702	06-034-1202	SHAFT	1
3	23703	06-034-1203	WASHER 12	1
4	10129	06-034-1204	CIRCLIP 12	1
5	23705	06-034-1205	REDUCTION GEAR	1
6	23706	06-034-1206	STARTER CLUTCH	1
7	10131	06-034-1207	SOCKET HEAD BOLT M8X16	3

Fig. 13 Clutch




Ref	Code	Part Number	Description	Qty
1	23801	06-034-1301	CLUTCH HOUSING	1
2	23802	06-034-1302	NUT M14X1	1
3	23803	06-034-1303	PRIMARY SLIDING SHEAVE	1
4	23804	06-034-1304	OIL SEAL	2
5	23805	06-034-1305	WEIGHT	8
6	23806	06-034-1306	CAM	1
7	23807	06-034-1307	SLIDER	4
8	23808	06-034-1308	O-RING 118X2.5	1
9	23809	06-034-1309	STOPPER	1
10	10132	06-034-1310	PAN HEAD SCREW M4X12	4
11	23811	06-034-1311	SPACER 1	4
12	23812	06-034-1312	COLLAR	1
13	23813	06-034-1313	WASHER PLATE 4	4
14	23814	06-034-1314	WASHER PLATE 14	1
15	23815	06-034-1315	V-BELT	1
16	23816	06-034-1316	SHEAVE PRIMARY FIXED	1
17	23802	06-034-1317	NUT M14X1	1
18	23818	06-034-1318	SECONDARY FIXED SHEAVE	1
19	23819	06-034-1319	SECONDARY SLIDING SHEAVE	1
20	23820	06-034-1320	OIL SEAL	2
21	23821	06-034-1321	O-RING 45X1.8	2
22	23822	06-034-1322	PIN GUIDE	4
23	23923	06-034-1323	COMPRESSION SPRING	1
24	23924	06-034-1324	SEAT SECONDARY SPRING	1
25	23925	06-034-1325	CLUTCH CARRIER ASSY	1
26	23926	06-034-1326	CLUTCH WEIGHT SPRING 1	3
27	10133	06-034-1327	CIRCLIP 8	3
28	23928	06-034-1328	NUT M36X1.5	1
29	23929	06-034-1329	DRIVEN ASSY COMPLETE	1
30	23930	06-034-1330	DRIVE ASSY COMPLETE	1

Fig. 14 Generator




Ref	Code	Part Number	Description	Qty
1	24001	06-034-1401	STATOR ASSY	1
2	24002	06-034-1402	ROTOR ASSY	1
3	10134	06-034-1403	SOCKET HEAD BOLT M5X25	3
4	10135	06-034-1404	SOCKET HEAD BOLT M5X12	2
5	24005	06-034-1405	GENERATOR ASSY	1
6	24006	06-034-1406	N/A	

Fig. 15 Starter Motor




Ref	Code	Part Number	Description	Qty
1	24101	06-034-1501	STARTING MOTOR ASSY	1
2	24102	06-034-1502	N/A	1
3	24103	06-034-1503	CORD,STARTER MOTOR	1
4	24104	06-034-1504	N/A	2
5	24105	06-034-1505	N/A	2
6	24106	06-034-1506	N/A	1
7	24107	06-034-1507	FLANGE BOLT M6X25	2

Fig. 16 Engine Mount




Ref	Code	Part Number	Description	Qty
1	24201	06-034-1601	FRONT ENGINE MOUNT	1
2	24202	06-034-1602	ENGINE MOUNT BOLT 1	2
3	24203	06-034-1603	BUSHING ENGINE MOUNT 1	2
4	10136	06-034-1604	NUT M12X1.25	2
5	24205	06-034-1605	ENGINE MOUNT BOLT 2	1
6	24206	06-034-1606	BUSHING ENGINE MOUNT 2	4
7	24207	06-034-1607	SPACER ENGINE MOUNT	1
8	10015	06-034-1608	NUT M10X1.25	1
9	10016	06-034-1609	BOLT M10X1.25X55	1
10	24210	06-034-1610	WASHER	1
11	10015	06-034-1611	NUT M10X1.25	1
12	10137	06-034-1612	BOLT M8X120	1
13	24213	06-034-1613	LEFT SPACER	2
14	24214	06-034-1614	STAY, ENGINE LEFT	1
15	10079	06-034-1615	NUT M8	1
16	10138	06-034-1616	BOLT M10X1.25X68	1
17	24217	06-034-1617	WASHER	1
18	24218	06-034-1618	STAY, ENGINE RIGHT	1
19	10015	06-034-1619	NUT M10X1.25	1
20	10139	06-034-1620	BOLT M8X65	1
21	24221	06-034-1621	RIGHT SPACER	2
22	24222	06-034-1622	ENGINE ASSY	1
23	24223	06-034-1623	BUSHING	2

Fig. 17 Front Differential




Ref	Code	Part Number	Description	Qty
1	10059	06-034-1701	BOLT M8X25	7
2	24302	06-034-1702	VENT FITTING	1
3	24303	06-034-1703	LEFT COVER	1
4	10122	06-034-1704	O-RING 18X2.65	1
5	24305	06-034-1705	DIFF FILLERPLUG	1
6	24306	06-034-1706	FOC BODY	1
7	24307	06-034-1707	RING GEAR	1
8	10202	06-034-1708	BEARING 6006	2
9	24309	06-034-1709	DIFFCASE RHS	1
10	24310	06-034-1710	SEAL SDD722X48X11	2
11	24311	06-034-1711	PINION GEAR	1
12	10062	06-034-1712	BEARING 6204	2
13	10074	06-034-1713	BEARING 6305ST	1
14	24314	06-034-1714	BEARING RETAINER	1
15	10287	06-034-1715	SCREW M6X12	4
16	24316	06-034-1716	DIFF GEAR	1
17	24317	06-034-1717	DIFF GEAR DRIVEN	1
18	24318	06-034-1718	SPLINED DOG	1
19	24319	06-034-1719	DIFF INPUTSHAFT A	1
20	10267	06-034-1720	BEARING 6205	1
21	24321	06-034-1721	SEAL TC25X47X7	1
22	10182	06-034-1722	BOLT M6X30	6
23	10160	06-034-1723	BOLT M6X70	1
24	24324	06-034-1724	REAR COVER	1
25	24325	06-034-1725	DIFF SELECTOR FORK	1
26	24326	06-034-1726	SELECTOR RAIL	1
27	24327	06-034-1727	PIN	1
28	24328	06-034-1728	SELECTOR SHAFT	1
29	24429	06-034-1729	SELECTOR COVER	1
30	10203	06-034-1730	STEEL BALL 8	1
31	24431	06-034-1731	SPRING	1
32	24431	06-034-1732	INDENT BALL INSERT	1

Fig. 17 Front Differential Cont.




Ref	Code	Part Number	Description	Qty
33	24432	06-034-1733	WASHER	1
34	10183	06-034-1734	BOLT M6X16	4
35	24435	06-034-1735	SEAL TC12X28X7	1
36	10168	06-034-1736	BOLT M8X16	1
37	24437	06-034-1737	FRONT PROPSHAFT ASSY	1
38	24438	06-034-1738	FRONT GEAR-BOX BACKSTOP	1
39	10208	06-034-1739	BOLT M10X1.25X43	2
40	10163	06-034-1740	BOLT M10X1.25X20	4
41	10209	06-034-1741	NUT M10	6
42	10355	06-034-1742	BOLT M8X1X16	1
43	10356	06-034-1743	NUT M8X1	1

Fig. 18 Front Axle




Ref	Code	Part Number	Description	Qty
1	24401	06-034-1801	DRIVE AXLE / OUTER CV ASSY	2
2	24402	06-034-1802	BOOT BAND "A"	4
3	24403	06-034-1803	OUTER BOARD BOOT	2
4	24404	06-034-1804	BOOT BAND "B"	2
5	24405	06-034-1805	SNAP RING	2
6	24406	06-034-1806	OUTER CV JOINT	2
7	24407	06-034-1807	CIRCLIP	2
8	24408	06-034-1808	BEARING	1
9	24409	06-034-1809	STOPPER RING	1
10	24410	06-034-1810	INBOARD BOOT	2

Fig. 19 2WD / 4WD Shift Linkage




Ref	Code	Part Number	Description	Qty
1	24501	06-034-1901	HANDLE	1
2	24502	06-034-1902	BRACKET	1
3	10103	06-034-1903	NUT M6	1
4	10212	06-034-1904	CIRCLIP 9	2
5	10116	06-034-1905	WASHER 10	2
6	24506	06-034-1906	WASHER	2
7	24507	06-034-1907	BRACKET	1
8	24508	06-034-1908	BUSH	1
9	24509	06-034-1909	LINKAGE 1	1
10	10213	06-034-1910	PIN A6X22	1
11	24511	06-034-1911	LINKAGE 2	1

Fig. 20 FOC




Ref	Code	Part Number	Description	Qty
1	24701	06-034-2001	RIGHT COVER	1
2	24702	06-034-2002	WASHER	2
3	24703	06-034-2003	PINION	2
4	24704	06-034-2004	HOUSING	1
5	24705	06-034-2005	CENTER SPACER	1
6	10003	06-034-2006	POLL PIN	2
7	24707	06-034-2007	CENTER PIN	2
8	24708	06-034-2008	BEVEL GEAR	2
9	24709	06-034-2009	CLUTCH PLATE OUTER DOUBLE	2
10	24710	06-034-2010	CLUITCH PLATE INNER	2
11	24711	06-034-2011	CLUTCH PLATE OUTER SINGLE	2
12	24712	06-034-2012	DISHED SPRING	4
13	24713	06-034-2013	WASHER	2
14	24714	06-034-2014	LEFT COVER	1
15	24715	06-034-2015	SPRING SEAT	2
16	10083	06-034-2016	SCREW M6X15	2
17	10131	06-034-2017	SCREW M8X16	6
18	24718	06-034-2018	BOLT M8X15	6

Fig. 21 Handlebar




Ref	Code	Part Number	Description	Qty
1	20104F	06-034-2101	INSTRUMENT HOUSING UPPER	1
2	20105F	06-034-2102	WARNING LIGHT	1
3	32030	06-034-2103	HAZARD LIGHT SWITCH	1
4	30110	06-034-2104	IGNITION SWITCH WITH KEY	1
5	30101F	06-034-2105	METER	1
6	10178	06-034-2106	SCREW ST4.2X13	10
7	20117F	06-034-2107	WARING LIGHT BRACKET1	1
8	20120	06-034-2108	INSTRUMENT HOUSING DOWN	1
9	10139	06-034-2109	BOLT M8X65	4
10	10068	06-034-2110	WASHER 8	4
11	10079	06-034-2111	NUT M8	4
12	20115a	06-034-2112	SWITCH ASSY	1
13	20116	06-034-2113	GRIP	2
14	10004	06-034-2114	NUT M6	2
15	20109	06-034-2115	THROTTLE CONTROL	1
16	20110	06-034-2116	HANDLEBAR	1
17	20114	06-034-2117	THROTTLE CABLE	1
18	20112a	06-034-2118	HANDLEBAR CLAMP	4
19	20124	06-034-2119	CUSHION	4
20	20125	06-034-2120	RUBBER RING 1	1
21	20121	06-034-2121	WARING LIGHT BRACKET 2	1
22	20122	06-034-2122	RUBBER RING	1

Fig. 22 Fuel Tank




Ref	Code	Part Number	Description	Qty
1	20201	06-034-2201	FUEL CAP	1
2	20202	06-034-2202	VENT TUBE	1
3	20203	06-034-2203	VENT FITTING	1
4	20204	06-034-2204	FOAM GASKET	1
5	10005	06-034-2205	BOLT M6X60	2
6	10006	06-034-2206	WASHER 6	2
7	20207	06-034-2207	MOUNTING BRACKET LEFT	1
8	20208a	06-034-2208	FUEL TANK	1
9	20209	06-034-2209	FOAM PAD	1
10	20210	06-034-2210	SPACER	2
11	20211	06-034-2211	MOUNTING PAD	2
12	20212	06-034-2212	FUEL HOSE	1
13	10007	06-034-2213	SCREW M4	1
14	10071	06-034-2214	WASHER 4	1
15	20215	06-034-2215	FUEL CONTROL KNOB	1
16	20216	06-034-2216	NUT	1
17	20217	06-034-2217	FUEL VALVE	1
18	20218	06-034-2218	HOSE CLAMP 1	9
19	20219	06-034-2219	FUEL LINE 2	1
20	20220	06-034-2220	FUEL FILTER	1
21	20221	06-034-2221	CLAMP	1
22	20222	06-034-2222	MOUNTING BRACKET RIGHT	1
23	20223	06-034-2223	FUEL LINE 1	1
24	30236	06-034-2224	PIPE 2	1
25	20225	06-034-2225	FUEL VALVE ASSY	1
26	20226	06-034-2226	FUEL FILTER PAD	1
27	10140	06-034-2227	BOLT M6X12	2
28	20228	06-034-2228	FUEL PUMP ASSY	1
29	20229	06-034-2229	HOSE CLAMP 2	7
30	20230	06-034-2230	FUEL LINE 3	1
31	20231	06-034-2231	PIPE	1
32	30232	06-034-2232	FUEL HOSE1	1
33	30233	06-034-2233	FUEL HOSE2	1
34	30234	06-034-2234	FUEL HOSE3	1
35	30235	06-034-2235	FUEL HOSE COUPLER	2
36	10308	06-034-2236	WASHER 6	2

Fig. 23 **Rear Fender / Seat**




Ref	Code	Part Number	Description	Qty
1	20301	06-034-2301	SEAT	1
2	20302	06-034-2302	SPRING	1
3	20303	06-034-2303	LATCH ASSEMBLY	1
4	20304	06-034-2304	RETAINER CLIP	2
5	10009	06-034-2305	SCREW ST4.8X16	4
6	10010	06-034-2306	BOLT M6X15	2
7	20307	06-034-2307	STORAGE BOX COVER	1
8	20308	06-034-2308	STORAGE BOX	1
9	20309	06-034-2309	REAR FENDER	1
10	10011	06-034-2310	WASHER 6	4
11	10010	06-034-2311	BOLT M6X15	42
12	20312	06-034-2312	LATCH BRACKET	1
13	20313a	06-034-2313	REAR MUD GUARD, RIGHT	1
14	20314b	06-034-2314	FOOTREST, RIGHT	1
15	20315	06-034-2315	BOLT M6X20	14
16	20316	06-034-2316	RUBBER PAD	14
17	20317a	06-034-2317	REAR MUD GUARD, LEFT	1
18	20318a	06-034-2318	FOOTREST, LEFT	1
19	20319	06-034-2319	BATTERY MOUNTING PAD	3
20	20320	06-034-2320	PLASTIC PLATE	1
21	20321	06-034-2321	FOOTREST RIGHT PAD	1
22	20322	06-034-2322	REAR MUD PAD A	2
23	20323	06-034-2323	REAR MUD PAD B	2
24	20324	06-034-2324	SEAT HINGE PAD	2
25	20325	06-034-2325	SEAT ASSY	1
26	20326	06-034-2326	TOOL	1

Fig. 24 Front Fender




Ref	Code	Part Number	Description	Qty
1	20401a	06-034-2401	FRONT COVER	1
2	20402F	06-034-2402	FRONT BODY	1
3	20403a	06-034-2403	SIDE COVER LEFT	1
4	20404a	06-034-2404	SIDE COVER RIGHT	1
5	20405a	06-034-2405	MUD GUARD RIGHT	1
6	10004	06-034-2406	NUT	40
7	20407a	06-034-2407	MUD GUARD LEFT	1
8	20408a	06-034-2408	FRAME COMP.	1
9	20409	06-034-2409	FRONT BODY FOAM	1
10	20410	06-034-2410	SMALL FRONT COVER	1
11	10009	06-034-2411	SCREW ST4.8X16	2
12	20412F	06-034-2412	UP BRACKET RADIATOR	1
13	20413F	06-034-2413	DOWN BRACKET RADIATOR	1
14	20414	06-034-2414	SPACER RUBBER	1
15	20415	06-034-2415	LEFT HEADLIGHT COVER UPPER	1
16	20416	06-034-2416	LEFT HEADLIGHT COVER LOWER	1
17	20417	06-034-2417	LEFT HEADLIGHT COVER	1
18	20418	06-034-2418	HEADLIGHT COVER	1
19	10178	06-034-2419	SCREW ST4.2X13	12
20	20420	06-034-2420	BOLT	12
21	10004	06-034-2421	NUT M6	12
22	20422	06-034-2422	RIGHT HEADLIGHT COVER UPPER	1
23	20423	06-034-2423	RIGHT HEADLIGHT COVER LOWER	1
24	20424	06-034-2424	RIGHT HEADLIGHT COVER	1
25	20418	06-034-2425	HEADLIGHT COVER	1
26	20426	06-034-2426	CUSHION 1	2
27	20427	06-034-2427	CUSHION 2	4
28	10270	06-034-2428	SCREW M5X30	2
29	10207	06-034-2429	WASHER 5	2
30	10206	06-034-2430	WASHER 4	2
31	20428	06-034-2431	CUSHION 3	2
32	10205	06-034-2432	SCREW ST3.5X13	2

Fig. 25 Front A-Arm




Ref	Code	Part Number	Description	Qty
1	10015	06-034-2501	NUT M10X1.25	2
2	10016	06-034-2502	BOLT M10X1.25X55	2
3	20503	06-034-2503	TIE ROD END A	2
4	10017	06-034-2504	JAM NUT(RIGHT)	2
5	20505	06-034-2505	TIE ROD	2
6	20506	06-034-2506	JAM NUT(LEFT)	2
7	20507	06-034-2507	TIE ROD END B	2
8	10018	06-034-2508	BOLT M10X1.25X55	2
9	10019	06-034-2509	WASHER	4
10	10020	06-034-2510	NUT M10X1.25	2
11	10021	06-034-2511	COTTER PIN	2
12	20512	06-034-2512	BALL JOINT STUD	2
13	20513	06-034-2513	BALL JOINT MOUNTING BRACKET	2
14	20514	06-034-2514	BALL JOINT CUP	2
15	10022	06-034-2515	BOLT M6X12	4
16	10023	06-034-2516	NUT M10	2
17	10021	06-034-2517	COTTER PIN	2
18	20518F	06-034-2518	A-ARM LEFT	1
19	20519	06-034-2519	A - ARM SHIELD LEFT	1
20	10001	06-034-2520	SCREW M5X12	4
21	20522F	06-034-2521	A-ARM PIVOT SHAFT	2
22	20629	06-034-2522	TIE ROD ASSY	2
23	10136	06-034-2523	NUT M12X1.25	4
24	20524F	06-034-2524	BUSHING	4
25	20627F	06-034-2525	A-ARM RIGHT	1
26	20628	06-034-2526	A - ARM SHIELD RIGHT	1

Fig. 26 Swingarm Assy




Ref	Code	Part Number	Description	Qty
1	20701	06-034-2601	REAR PROPSHAFT ASSY	1
2	10029	06-034-2602	O-RING	1
3	20703	06-034-2603	COUPLING-PROP SHAFT GREASE	1
4	20704	06-034-2604	SWINGARM ASSY	1
5	20705	06-034-2605	SKID PLATE REAR	1
6	20706	06-034-2606	SEAL-SWINGARM PIVOT	2
7	10030	06-034-2607	BEARING	2
8	20708	06-034-2608	SEAL	2
9	20709	06-034-2609	SWING ARM PIVOT RIGHT	1
10	20710	06-034-2610	THREADED PIVOT	1
11	10031	06-034-2611	NUT M12	7
12	10032	06-034-2612	WASHER 12	7
13	10045	06-034-2613	BOLT M12X30	3
14	10034	06-034-2614	BOLT M8X12	3
15	20715	06-034-2615	CAP SWINGARM PIVOT	2
16	20716	06-034-2616	ROLL PIN	1
17	20717	06-034-2617	SWINGARM PIVOT LEFT	1
18	20718	06-034-2618	SPONGY GASKET	1

Fig. 27 Front Wheel




Ref	Code	Part Number	Description	Qty
1	10035	06-034-2701	BOLT M8X20	8
2	NA	NA	NA	2
3	10030	06-034-2703	BEARING	4
4	20804	06-034-2704	SEAL SLEEVE	2
5	20805T	06-034-2705	HUB ASSY SHRT	2
6	20806	06-034-2706	WHEEL STUD	8
7	20807	06-034-2707	PLUG PIPE	2
8	20808	06-034-2708	TIRE FRONT	2
9	20809	06-034-2709	WHEEL FRONT	2
10	10037	06-034-2710	WASHER 16	2
11	20811	06-034-2711	SLOTTED NUT M16X1.5	2
12	10038	06-034-2712	COTTER PIN	2
13	10039	06-034-2713	O-RING	2
14	20814	06-034-2714	HUB CAP 2-LOBE AWD	2
15	10040	06-034-2715	SCREW M5X16	6
16	10015	06-034-2716	LUG NUT M10X1.25	8
17	20817	06-034-2717	LUG	1
18	20818	06-034-2718	WASHER	1

Fig. 28 Rear Shock / Axle




Ref	Code	Part Number	Description	Qty
1	20901	06-034-2801	O-RING	1
2	20902	06-034-2802	BUSHING	2
3	20903	06-034-2803	SPACER	1
4	10042	06-034-2804	O-RING	1
5	20905a	06-034-2805	REAR AXLE	1
6	20906	06-034-2806	BOLT M10X1.25X57	1
7	10015	06-034-2807	NUT M10X1.25	2
8	20908	06-034-2808	SHOCK ABSORBER REAR	1
9	20909	06-034-2809	BOLT M10X1.25X57	1

Fig. 29 Rear Wheel




Ref	Code	Part Number	Description	Qty
1	10032	06-034-2901	WASHER 12	8
2	10045	06-034-2902	BOLT M12X30	4
3	21003	06-034-2903	AXLE TUBE AND HITCH ASSY LEF	1
4	21004	06-034-2904	CIRCLIP	2
5	21005	06-034-2905	SPACER	2
6	10046	06-034-2906	BEARING BALL DBL SEAL	4
7	10047	06-034-2907	CIRCLIP	1
8	21008	06-034-2908	SPACER-BEARING	2
9	21009	06-034-2909	SEAL REAR AXLE	2
10	10048	06-034-2910	BOLTS M10X1.25X20	3
11	10221	06-034-2911	O-RING	2
12	21012	06-034-2912	HUB, BRAKE DISC	2
13	10050	06-034-2913	NUT M10X1.25	3
14	21014	06-034-2914	AXLE CAP	2
15	10051	06-034-2915	COTTER PIN	2
16	10142	06-034-2916	NUT SLOTTED M20X2	2
17	21017	06-034-2917	WASHER	2
18	21018	06-034-2918	HUB, WHEEL	2
19	21019	06-034-2919	LUG NUT M12X1.25	2
20	21020	06-034-2920	TIRE REAR	2
21	10053	06-034-2921	WHEEL STUD M12X1.25X45	8
22	21022	06-034-2922	WHEEL REAR	2
23	10054	06-034-2923	WASHER 12	8
24	21024	06-034-2924	BRAKE HOSE COVER	1
25	21025	06-034-2925	AXLE TUBE AND HITCH ASSEMBL	1
26	10033	06-034-2926	BOLT M12X35	4
27	21026	06-034-2927	WHEEL WASHER	8

Fig. 30 Rear Differential




Ref	Code	Part Number	Description	Qty
1	10055	06-034-3001	BOLT M8X45	2
2	21102	06-034-3002	SEAL 50X70X8	1
3	21103	06-034-3003	OUTPUT COVER	1
4	21104	06-034-3004	DOWEL PIN	1
5	21105	06-034-3005	O-RING 176X2.65	1
6	21106	06-034-3006	SHIM	1
7	21107	06-034-3007	SHIM	1
8	21108	06-034-3008	THRUST BUTTON	1
9	10056	06-034-3009	BEARING 110	2
10	21110	06-034-3010	RING GEAR	1
11	21111	06-034-3011	VENT	1
12	21112	06-034-3012	TUBE, VENT	1
13	21113	06-034-3013	DRIVE HOUSING	1
14	21114	06-034-3014	OIL PLUG	2
15	21115	06-034-3015	WASHER	2
16	21102	06-034-3016	SEAL 50X70X8	1
17	10057	06-034-3017	BUSHING P23X20X15	1
18	21118	06-034-3018	PINION SHAFT	1
19	10058	06-034-3019	BEARING 6306ST	1
20	21120	06-034-3020	RETAINER 30	1
21	20901	06-034-3021	O-RING 79X4	1
22	21122	06-034-3022	INPUT COVER	1
23	10059	06-034-3023	BOLT M8X25	10
24	21124	06-034-3024	SEAL 25X35X5	1
25	21125	06-034-3025	REAR GEARBOX ASSY	1

Fig. 31 Transmission



Ref	Code	Part Number	Description	Qty
1	21201	06-034-3101	SEAL 25X47X8	1
2	10060	06-034-3102	BOLT M8X28	17
3	21203	06-034-3103	MAIN COVER	1
4	21104	06-034-3104	DOWEL PIN	2
5	10061	06-034-3105	BEARING 6205c3	4
6	21206	06-034-3106	INPUT SHAFT	1
7	21207	06-034-3107	CHAIN	1
8	21208	06-034-3108	GEAR 16T	1
9	10062	06-034-3109	BEARING 6204	3
10	21210	06-034-3110	GEAR,HELICAL 35T	1
11	21211	06-034-3111	INTERLOCK PIN	2
12	21212	06-034-3112	INTERLOCK BRACKET	1
13	21213	06-034-3113	SPRING	1
14	21211	06-034-3114	INTERLOCK PIN	1
15	10001	06-034-3115	SCREW M5X12	2
16	21216	06-034-3116	SPACER	1
17	21217	06-034-3117	GEAR 31T	1
18	21218	06-034-3118	NEEDLE BEARING 25	1
19	21219	06-034-3119	THRUST WASHER	1
20	10064	06-034-3120	SNAP RING	1
21	21221	06-034-3121	DOG GEAR	1
22	10065	06-034-3122	SNAP RING	1
23	21223	06-034-3123	THRUST WASHER	1
24	21224	06-034-3124	SPROCKET 24T	1
25	21225	06-034-3125	NEEDLE BEARING 25	1
26	21223	06-034-3126	THRUST WASHER	1
27	21327	06-034-3127	SHAFT	1
28	21218	06-034-3128	NEEDLE BEARING 25	1
29	21329	06-034-3129	GEAR 35T	1
30	21223	06-034-3130	THRUST WASHER	1
31	10064	06-034-3131	SNAP RING	1
32	21332	06-034-3132	ENGAGEMENT	1
33	21333	06-034-3133	THRST WASHER	1
34	10067	06-034-3134	NUT M8	2
35	10068	06-034-3135	WASHER 8	2
36	21336	06-034-3136	BELLCRANK	2
37	10069	06-034-3137	SNAP RING	2
38	21338	06-034-3138	WASHER	2


Fig. 31 Transmission Cont.



Ref	Code	Part Number	Description	Qty
39	21339	06-034-3139	VENT TUBE	1
40	21340	06-034-3140	VENT TUBE FITTING	1
41	21341	06-034-3141	SHIFT FORK HIGH/REVERSE	1
42	10007	06-034-3142	SCREW M4	8
43	10071	06-034-3143	WASHER 4	8
44	21344	06-034-3144	GEAR INDICATOR SWITCH	1
45	21345a	06-034-3145	GEARCASE,RH	1
46	21201	06-034-3146	SEAL 25X47X8	1
47	21475	06-034-3147	DIPSTICK	1
48	10275	06-034-3148	BUSHING	1
49	10063	06-034-3149	BEARING 6204C3	1
50	21350	06-034-3150	GEAR HELICAL 46T	1
51	10073	06-034-3151	SCREW M6X10	4
52	21351	06-034-3152	BEARING RETAINER PLATE	1
53	21453	06-034-3153	SNAP RING	1
54	10074	06-034-3154	BEARING 6305ST	1
55	21455	06-034-3155	PINION SHAFT 10T	1
56	21456	06-034-3156	SHIFT FORK LOW	1
57	21457	06-034-3157	GEAR INDICATOR SWITCH	1
58	10075	06-034-3158	SNAP RING	2
59	21459	06-034-3159	SHIFT ROD LOW	1
60	21460	06-034-3160	SHIFT ROD HIGH/REVERSE	1
61	21461	06-034-3161	THRUST WASHER	1
62	21483	06-034-3162	SPORCKET 12T	1
63	21463	06-034-3163	SHAFT REAR OUTPUT	1
64	21464	06-034-3164	THRUST BUTTON	1
65	21465	06-034-3165	SHIM 1	1
66	21466	06-034-3166	SHIM 2	1
67	21104	06-034-3167	DOWEL PIN	1
68	21468T	06-034-3168	COVER	1
69	21469	06-034-3169	DRAIN SCREW	1
70	21470	06-034-3170	WASHER	1
71	21471T	06-034-3171	TRANSMISSION ASSY	1
72	21462	06-034-3172	GEAR	1
73	10122	06-034-3173	O RING 18X2.65	1
74	21477	06-034-3174	SPROCKET	1
75	21480	06-034-3175	SHAFT FRONT OUTPUT	1
76	21481	06-034-3176	SPROCKET 12T	1


77	21482	06-034-3177	CHAIN	1
----	-------	-------------	-------	---

Fig. 32 Support Bracket, Transmission




Ref	Code	Part Number	Description	Qty
1	10076	06-034-3201	BOLT M12X20	2
2	10054	06-034-3202	WASHER 12	2
3	21503	06-034-3203	TRANS MOUNTING BRACKET RG	1
4	21504	06-034-3204	TRANS MOUNTING BRACKET LFT	1
5	10078	06-034-3205	BOLT M8X30	3
6	10079	06-034-3206	NUT M8	2
7	10028	06-034-3207	BOLT M10X25	2
8	21508	06-034-3208	TRANS MOUNTING BRACKET BO	1
9	10081	06-034-3209	BOLT M8X20	2
10	10027	06-034-3210	WASHER10	1
11	10019	06-034-3211	WASHER	1
12	10084	06-034-3212	BOLT M10X1.25X70	2
13	10015	06-034-3213	NUT M10	2
14	21514	06-034-3214	TRANS MOUNTING BRACKET REA	1

Fig. 33 Shift Rod




Ref	Code	Part Number	Description	Qty
1	21601a	06-034-3301	LABEL	1
2	21729a	06-034-3302	SHIFTER ASSY MOUNTING	1
3	21603a	06-034-3303	KNOB	1
4	21604a	06-034-3304	SHIFT LEVER	1
5	10086	06-034-3305	SCREW M6X12	4
6	10006	06-034-3306	WASHER 6	4
7	21607	06-034-3307	BOOT	1
8	21608	06-034-3308	SHIFTER COUPLING	1
9	21609	06-034-3309	GROOVE PIN	1
10	21610	06-034-3310	CENTERING SPRING	1
11	21611	06-034-3311	DETENT SPRING	2
12	21612	06-034-3312	DETENT BULLET	2
13	21613	06-034-3313	DOWEL PIN	1
14	21614	06-034-3314	SHIFTER HOUSING	1
15	21615	06-034-3315	O-RING	2
16	21616	06-034-3316	SELECTOR SLIDES HIGH/REVERSE	2
17	21617	06-034-3317	SHIFTER MOUNTING BRACKET	1
18	10010	06-034-3318	BOLT M6X15	4
19	21619	06-034-3319	SHIFT ROD COUPLER	1
20	21620	06-034-3320	SHIFT ROD END CW	2
21	10090	06-034-3321	JAM NUT M6 CW	3
22	21622	06-034-3322	SHIFT ROD HIGH/REVERSE	1
23	21623	06-034-3323	SHIFT ROD LOW	1
24	21624	06-034-3324	JAM NUT M6 CCW	2
25	21625	06-034-3325	SHIFT ROD END CCW	2
26	21626	06-034-3326	SELECTOR SLIDES LOW	1
27	21727	06-034-3327	SHIFTER MOUNTING ROD A	1
28	21728	06-034-3328	SHIFTER MOUNTING ROD B	1

Fig. 34 Shock Absorber, Front




Ref	Code	Part Number	Description	Qty
1	10091	06-034-3401	NUT M14X1.5	2
2	21802	06-034-3402	WASHER 14	2
3	21803	06-034-3403	SPACER RUBBER	2
4	21804	06-034-3404	UPPER PIVOT BALL	2
5	10093	06-034-3405	BOLT M8X55	4
6	21806	06-034-3406	NUT M14X1.5	2
7	21807	06-034-3407	LOWER PIVOT BALL	2
8	21808	06-034-3408	SPRING RETAINER	2
9	21809	06-034-3409	SPRING	2
10	21810	06-034-3410	STRUT BUMPER	2
11	21811	06-034-3411	CLAMP	2
12	10079	06-034-3412	NUT M8	4
13	21813	06-034-3413	SPRING RETAINER	2
14	21814	06-034-3414	STRUT BODY LEFT	1
15	21815	06-034-3415	SPINDLE BOLT	2
16	10095	06-034-3416	BEARING	4
17	10026	06-034-3417	GREASE FITTING	2
18	21818	06-034-3418	SEAL SLEEVE	2
19	21819	06-034-3419	STRUT BODY RIGHT	1

Fig. 35 Steering Column




Ref	Code	Part Number	Description	Qty
1	10079	06-034-3501	NUT M8	2
2	10026	06-034-3502	GREASE FITTING	1
3	21903	06-034-3503	BUSHING	2
4	21904	06-034-3504	STEERING CLAMP REAR	1
5	21905	06-034-3505	STEERING CLAMP FRONT	1
6	21906	06-034-3506	BOLT	2
7	21907F	06-034-3507	STEERING COLUMN	1
8	21906	06-034-3508	BOLT	2
9	21909	06-034-3509	WASHER	2
10	21910	06-034-3510	BEARING RETAINER	1
11	21911	06-034-3511	BEARING	1
12	10079	06-034-3512	NUT M8	2
13	10100	06-034-3513	STEERING COLUMN RETAINER N	1
14	10101	06-034-3514	COTTER PIN	1

Fig. 36 Electrical




Ref	Code	Part Number	Description	Qty
1	22001	06-034-3601	CDI	1
2	22002	06-034-3602	REVERSE SPEED LIMITER	1
3	22003	06-034-3603	BATTERY CABLE POSITIVE	1
4	22004	06-034-3604	STARTER RELAY	1
5	22005	06-034-3605	BATTERY	1
6	22006	06-034-3606	BATTERY CABLE GROUND	1
7	22007	06-034-3607	REGULATOR RECTIFIER	1
8	22008	06-034-3608	WARNING BUZZER	1
9	32009F	06-034-3609	HEADLIGHT ASSEMBLY	1
10	22010	06-034-3610	TAIL LIGHT	1
11	32011F	NA	NA	1
12	22012	06-034-3612	IGNITION COIL AND WIRE	1
13	22013	06-034-3613	INDICATOR LIGHT WIRING HARNESS	1
14	22014	06-034-3614	ENGINE TEMPERATURE SENSOR	1
15	32011G	NA	NA	1
16	22016	06-034-3616	HEAD LIGHT BULB	2
17	22017	06-034-3617	TAIL LIGHT BULB	1
18	22018	06-034-3618	BATTERY STRAP	1
19	22019	06-034-3619	7.5 AMP FUSE	1
20	22020	06-034-3620	15 AMP FUSE	2
21	22021	06-034-3621	3 AMP FUSE	1
22	22022	06-034-3622	HORN	1
23	22023	06-034-3623	???	1
24	42519	06-034-3624	FREEZE PROOF DEVICE	1
25	32019F	06-034-3625	FRONT TURN INDICATOR RIGHT	1
26	32022F	06-034-3626	FRONT TURN INDICATOR LEFT	1
27	32023F	06-034-3627	REAR TURN INDICATOR RIGHT	1
28	32024F	06-034-3628	REAR TURN INDICATOR LEFT	1
29	22011a	NA	NA	1
30	32011T	06-034-3630	WIRING HARNESS	1

Fig. 37 Brake System




Ref	Code	Part Number	Description	Qty
1	22101	06-034-3701	MASTER CYLINDER W/ BRAKE LE	1
2	22102	06-034-3702	HOSE 1	1
3	22103	06-034-3703	REAR BRAKE HOSE	1
4	22104a	06-034-3704	REAR HAND BRAKE HOSE	1
5	22250	06-034-3705	BRAKE CALIPER LEFT	2
6	10224	06-034-3706	BOLT M10X1.25X83	4
7	10019	06-034-3707	WASHER 10	4
8	10015	06-034-3708	NUT M10X1.25	4
9	22109	06-034-3709	WASHER	8
10	22110	06-034-3710	SPACER	2
11	22111	06-034-3711	REAR BRAKE PAD SET	2
12	22112	06-034-3712	RETAINING PIN	2
13	22113	06-034-3713	BANJO BOLTS	4
14	22114	06-034-3714	BRAKE CALIPER LEFT	1
15	10105	06-034-3715	BOLT M8X25	4
16	10106	06-034-3716	WASHER 8	4
17	10068	06-034-3717	WASHER 8	4
18	22118a	06-034-3718	FOOT BRAKE HOSE	1
19	10108	06-034-3719	BOLT M5X12	1
20	10109	06-034-3720	NUTM5	1
21	22121	06-034-3721	MASTER CYLINDER, FOOT BRAKE	1
22	10110	06-034-3722	BOLT M6X20	2
23	22123	06-034-3723	BRAKE HOSE	1
24	22124	06-034-3724	CLAMP	2
25	22125	06-034-3725	RESERVOIR	1
26	22226	06-034-3726	FRONT BRAKE DISC	2
27	22227	06-034-3727	BRAKE CALIPER RIGHT	1
28	22228	06-034-3728	FRONT BRAKE HOSE, RIGHT	1
29	22229	06-034-3729	FRONT BRAKE HOSE, LEFT	1
30	22230	06-034-3730	BRAKE LINE COUPLER	1
31	10111	06-034-3731	SCREW M5X15	2
32	10004	06-034-3732	NUT M6	2
33	10113	06-034-3733	BOLT M5X8	1
34	10113	06-034-3734	BOLT M5X8	6
35	22235	06-034-3735	BRAKE LINE CLAMP SMALL	1

Fig. 37 Brake System Cont.



Ref	Code	Part Number	Description	Qty
36	22236	06-034-3736	BRAKE LINE CLAMP LARGE	3
37	10115	06-034-3737	RETAINER	1
38	22238	06-034-3738	WASHER	1
39	22239a	06-034-3739	BRAKE PEDAL	1
40	10110	06-034-3740	BOLT M6X20	3
41	22241a	06-034-3741	FOOT BRAKE MOUNTING PLATE	1
42	22242a	06-034-3742	RETURN SPRING	1
43	22243	06-034-3743	SWITCH ASSY.STOP	1
44	22244	06-034-3744	BRAKE ASSY	1
45	22245	06-034-3745	FRONT BRAKE PAD SET	2
46	22247	06-034-3746	REAR BRAKE DISC	2
47	22251	06-034-3747	BRAKE CALIPER RIGHT	2
48	22249	06-034-3748	ADIABATIC PELLICKE	1

Fig. 38 Bumper and Rack



Ref	Code	Part Number	Description	Qty
1	10081	06-034-3801	BOLT M8X20	8
2	10079	06-034-3802	NUT M8	2
3	32303F	06-034-3803	BUMPER	1
4	22304F	06-034-3804	SUPPORT 1 LEFT	1
5	10118	06-034-3805	BOLT M8X95	2
6	22306F	06-034-3806	SUPPORT 2 LEFT	1
7	32307F	06-034-3807	FRONT RACK FRAME	1
8	22308	06-034-3808	SUPPORT 3 LEFT	1
9	10225	06-034-3809	BOLT M8X72	4
10	32310F	06-034-3810	REAR FRAME	1
11	22311F	06-034-3811	SUPPORT 1 RIGHT	1
12	22312	06-034-3812	SUPPORT 2 RIGHT	1
13	22313	06-034-3813	SUPPORT 3 RIGHT	1
14	10079	06-034-3814	NUT M8	4
15	10010	06-034-3815	BOLT M6X15	4
16	22325F	06-034-3816	SIDE GRILL	2
17	10067	06-034-3817	NUT M8	2
18	10124	06-034-3818	BOLTM8X35	6
19	10055	06-034-3819	BOLTM8X45	4
20	22320	06-034-3820	FRONT REFLECTOR	4
21	22321	06-034-3821	REAR REFLECTOR	2
22	22322	06-034-3822	CONNECTION BRACKET	1
23	10059	06-034-3823	BOLT M8X25	2