

DIAMO® Discovery ATV
PARTS CATALOG - CHASSIS

First Edition April 2008





Copyright © 2004-2008 LS MotorSports, LLC. Reproduction without written permission is completely forbidden.

*The information and diagrams included in this catalog are the exclusive property of LS MotorSports, LLC
and may not be reproduced in any media without the express written consent of LS MotorSports, LLC.
For more information contact:*

LS MotorSports, LLC
10215 S Sam Houston Pkwy, Suite 100
Houston, TX 77071
281-277-6140

*Information contained in this publication is subject to change without notice.
For the most up to date information please contact DIAMO USA or an Authorized Dealer*



www.DIAMOUSA.com



Copyright © 2004-2008 LS MotorSports, LLC. Reproduction without written permission is completely forbidden.

CONTENTS

PAGE

4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41


TITLE

Documents
Frame
Electrical
Radiator
Handlebar
Left Handlebar Control
Steering Stem
Air Filter
Exhaust
Front Suspension
Rear Shock and Sway Bar
Rear A-Arm
Front Wheel and Axle
Front Differential
Rear Wheel and Axle
Final Drive and Drive Shaft
Rear Master Cylinder
Rear Brake
Crankcase Air Ducts
Shifter
Tail Light
Fuel Tank
Front Master Cylinder
Front Brake
Footrest
Instruments
Seat
Side Covers
Rack and Guard
Rear Cover
Front Cover
Headlight
Tail Light 2
Emblem 1
Emblem 2
Evap Kit
Brake System Assembly
Lock Set

Fig. 00 Documents


Ref	Code	Part Number	Description	Qty
1		08-039-0001	Owners Manual	1
2		08-039-0002	Parts Catalog CD	1
3		08-039-0003	Service Manual	1

Fig. 01 Frame




Ref	Code	Part Number	Description	Qty
1	51100-058-0000	08-039-0101	Frame	
2	54305-058-0000	08-039-0102	Bracket, Engine	
3	GB/T16674-96	08-039-0103	Bolt M8X20	
4	GB/T16674-96	08-039-0104	Bolt M6X16	
5	GB/T16674-96	08-039-0105	Bolt M8X16	
6	54306-058-0000	08-039-0106	Stay, Engine 2	
7	GB/T16674-96	08-039-0107	Bolt M8X20	
8	GB/T16674-96	08-039-0108	Bolt M6X16	
9	GB/T16674-96	08-039-0109	Bolt M8X16	
10	54320-058-0000	08-039-0110	Damper 1	
11	GB/T6187.1-2000	08-039-0111	Nut M10X1.25	
12	GB/T16674-96	08-039-0112	Bolt M10X1.25X170	
13	GB/T6187.1-2000	08-039-0113	Nut M10X1.25	
14	GB/T16674-96	08-039-0114	Bolt M6X16	
15	54330-058-0000	08-039-0115	Damper 2	
16	GB/T6187.1-2000	08-039-0116	Nut M10X1.25	
17	62118-023-0000	08-039-0117	Bearing 6203RS, Steering Shaft	
18	62121-023-0000	08-039-0118	Oil Seal	
19	62122-023-0000	08-039-0119	Oil Seal	
20	62119-023-0000	08-039-0120	Nut M12X1	
21	GB/T16674-96	08-039-0121	Bolt M10X1.25X25	
22	GB95-85	08-039-0122	Washer	
23	GB/T16674-96	08-039-0123	Bolt M10X1.25X115	
24	GB/T6187.1-2000	08-039-0124	Nut M10X1.25	
25	GB95-85	08-039-0125	Washer	
26	19250-058-0000	08-039-0126	Stay, Front Cover	
27	GB/T16674-96	08-039-0127	Bolt M6X12	
28	GB/T16674-96	08-039-0128	Bolt M10X1.25X115	
29	GB/T6187.1-2000	08-039-0129	Nut M10X1.25	
30	GB97-85	08-039-0130	Washer	
31	23470-058-0000	08-039-0131	Bracket, Shifter	
32	GB/T16674-96	08-039-0132	Bolt M8X20	
33	85100-058-0000	08-039-0133	Tool Kit	
34	85103-058-0000	08-039-0134	Tire Gauge	
35	91201-058-0000	08-039-0135	O-Ring	
36	72302-058-0000	08-039-0136	Hitch	
37	GB/T16674-96	08-039-0137	Screw M10X1.25X25	
38	82801-058-0000	08-039-0138	Guard, Engine 1	
39	90101-058-0000	08-039-0139	Bolt M6X16-10X4	
40	90101-058-0000	08-039-0140	Bolt M6X16-10X4	
41	82802-058-0000	08-039-0141	Guard, Engine 2	
42	82803-058-0000	08-039-0142	Guard, Engine 3	
43	90101-058-0000	08-039-0143	Bolt M6X16-10X4	
44	90101-058-0000	08-039-0144	Bolt M6X16-10X4X12	
45	GB/T16674-96	08-039-0145	Bolt M6X12	
46	19260-058-0000	08-039-0146	Support, Radiator	
47	GB/T16674-96	08-039-0147	Bolt M6X12	
48	54250-058-0000	08-039-0148	Bracket, Tail Light	

Fig. 02 Electrical




Ref	Code	Part Number	Description	Qty
1	33200-058-0000	08-039-0201	CDI	
2	90302-025-0000	08-039-0202	Nut M6,2X25	
3	90302-058-0000	08-039-0203	Plastic Nut	
4	34600-023-0000	08-039-0204	N/A	
5	34112-058-0000	08-039-0205	Wire, Lead	
6	34100-058-0000	08-039-0206	Main Harness	
7	37125-058-0000	08-039-0207	Reverse Switch	
8	GB95-85	08-039-0208	Washer	
9	33100-058-0000	08-039-0209	Ignition Coil	
10	GB/T5783-2000	08-039-0210	Bolt M6X20	
11	GB/T5783-2000	08-039-0211	Bolt M6X20	
12	GB95-85	08-039-0212	Washer	
13	33101-058-0000	08-039-0213	Spark Plug Cap	
14	19410-058-0000	08-039-0214	Thermo Switch	
15	19430-058-0000	08-039-0215	Thermo Switch, Fan	
16	36510-058-0000	08-039-0216	Speed Sensor	
17	36511-058-0000	08-039-0217	Cable, Speed Sensor	
18	32100-058-0000	08-039-0218	Voltage Regulator	
19	GB/T16674-96	08-039-0219	Bolt M6X20	
20	32200-058-0000	08-039-0220	Battery 12V21Ah	
21	32201-058-0000	08-039-0221	Holddown, Battery	
22	32202-023-0000	08-039-0222	Rubber Washer	
23	32203-058-0000	08-039-0223	Cover, Battery	
24	90302-025-0000	08-039-0224	Plastic Nut M6X25	
25	GB9456-88	08-039-0225	Screw ST6X15	
26	34102-058-0000	08-039-0226	Cable, Plus Lead	
27	34101-058-0000	08-039-0227	Cable, Minus Lead	
28	32501-058-0000	08-039-0228	Fuse(15A-BC)	
29	37700-023-0000	08-039-0229	Starter Relay	
30	32504-023-0000	08-039-0230	Fuse, Starter Relay	
31	GB/16674-96	08-039-0231	Bolt M6X10	
32	37200-058-0000	08-039-0232	Ignition Switch	
33	16140-F39-0000	08-039-0233	Hose, Carburetor C300	
34	16141-F39-0000	08-039-0234	Hose, Carburetor B80	
35	32502-058-0000	08-039-0235	Fuse(10A-BC)	
36	16130-F39-0000	08-039-0236	Hose, CarburetorA80	
37	90402-058-0000	08-039-0237	Clip	
38	34500-058-0000	08-039-0238	Horn - N/A	
39	16601-025-0000	08-039-0239	T-Fitting	
40	91523-058-0000	08-039-0240	Tie 1	
41	34115-058-0000	08-039-0241	Cable , Ignition	
42	37910-058-0000	08-039-0242	Relay 1	
43	37920-058-0000	08-039-0243	Relay 2	
44	37600-058-0000	08-039-0244	Rear Brake Light Switch	
45	34120-058-0000	08-039-0245	Wire, Sub-Lead	
46	32902-058-0000	08-039-0246	Nut, 12V Accessory Plug	
47	32901-058-0000	08-039-0247	12V Accessory Plug	
48	34500-058-0000	08-039-0248	Spring, Rear Brake Light Switch	
49	32503-058-0000	08-039-0249	Fuse(5A-BC)	
50	37126-058-0000	08-039-0250	Reverse Switch	

Fig. 03 Radiator




Ref	Code	Part Number	Description	Qty
1	19811-023-0000	08-039-031	Hose 1	
2	19611-023-0000	08-039-032	Clamp	
3	19230-058-0000	08-039-033	Fan	
4	19202-058-0000	08-039-034	Cushion	
5	19206-058-000	08-039-035	Bushing	
6	GB/T96-85	08-039-036	Washer	
7	GB/T16674-96	08-039-037	Bolt M6X20	
8	19201-058-0000	08-039-038	Radiator Cap	
9	19210-58-0000	08-039-039	Radiator	
10	90311-058-0000	08-039-040	Nut	
11	19812-023-0000	08-039-041	Hose 2	
12	90402-058-0000	08-039-042	Clamp	
13	GB/T818-2000	08-039-043	Screw M6X25	
14	GB/T96-85	08-039-044	Washer	
15	19200-058-0000	08-039-045	Radiator and Fan Assy	
16	19205-058-0000	08-039-046	Guard, Radiator	

Fig. 04 Handlebar




Ref	Code	Part Number	Description	Qty
1	61101-058-0000	08-039-0401	Handlebar	
2	61104-058-0000	08-039-0402	Grip	
3	61600-058-0000	08-039-0403	Choke Cable	
4	61700-058-0000	08-039-0404	Throttle Assy	
5	61500-058-0000	08-039-0405	Throttle Cable	
6	61750-058-0000	08-039-0406	2WD/4WD Switch	
7	61730-058-0000	08-039-0407	Throttle Control	

Fig. 05 Left Handlebar Control




Ref	Code	Part Number	Description	Qty
1	61210-058-0000	08-039-0501	Rear Brake Lever Assy	
2	61211-023-0000	08-039-0502	Holder, RR Brake Lever	
3	61212-023-0000	08-039-0503	Clamp	
4	61213-023-0000	08-039-0504	Lever, RR Brake	
5	61214-023-0000	08-039-0505	Bolt, RR Brake Lever	
6	GB/T6182.1-2000	08-039-0506	Nut M6	
7	GB/T818-2000	08-039-0507	Screw M6X16	
8	GB/T93-87	08-039-0508	Washer	
9	43206-058-0000	08-039-0509	Brake Light Switch, RR Brake Lever	
10	42106-058-0000	08-039-0510	Bolt	
11	42107-058-0000	08-039-0511	Nut	
12	37400-058-0000	08-039-0512	Left Combination Switch	

Fig. 06 Steering Stem




Ref	Code	Part Number	Description	Qty
1	62120-058-0000	08-039-0601	Steering Column	
2	62130-058-0000	08-039-0602	Pitman Arm	
3	61102-023-0000	08-039-0603	Clamp, Handle Bar	
4	GB/T16674-96	08-039-0604	Bolt M8X50	
5	62112-023-0000	08-039-0605	Clamp, Steering Column	
6	62113-023-0000	08-039-0606	Oil Seal	
7	62125-058-0000	08-039-0607	Bracket, Steering Column	
8	GB/T5783-2000	08-039-0608	Bolt M8X60	
9	62106-023-0000	08-039-0609	Washer, Special	
10	62114-023-0000	08-039-0610	Collar, Steering Stem	
11	GB/T96-85	08-039-0611	Washer	
12	GB/T9457-1988	08-039-0612	Nut M14	
13	GB/T91-2000	08-039-0613	Cotter Pin	
14	62200-058-0000	08-039-0614	Tie Rod Assy	
15	GB/T96-85	08-039-0615	Washer	
16	GB/T9457-1988	08-039-0616	Nut M12X1	
17	GB/T91-2000	08-039-0617	Cotter Pin	
18	62210-058-0000	08-039-0618	Tie Rod End, Inner	
19	62220-058-0000	08-039-0619	Tie Rod End, Outter	
20	62201-058-0000	08-039-0620	Tie Rod	

Fig. 07 Air Filter




Ref	Code	Part Number	Description	Qty
1	17151-058-0000	08-039-0701	Clamp, Carburetor	
2	17118-023-0000	08-039-0702	Pipe	
3	17104-058-0000	08-039-0703	Joint, Air Cleaner	
4	17152-058-0000	08-039-0704	Clamp, Air Cleaner	
5	17102-058-0000	08-039-0705	Grommet	
6	GB/T845-1985	08-039-0706	Screw ST6.2X25	
7	17160-058-0000	08-039-0707	Air Filter Element	
8	17100-058-0000	08-039-0708	Air Filter Assy	
9	17130-058-0000	08-039-0709	Cover, Air Filter	
10	17180-058-0000	08-039-0710	Body, Air Filter	
11	GB/T818-1985	08-039-0711	Screw	
12	90302-023-0000	08-039-0712	Nut	

Fig. 08 Exhaust




Ref	Code	Part Number	Description	Qty
1	18110-058-0000	08-039-0801	Exhaust Pipe	
2	GB/T16674-96	08-039-0802	Bolt M8X12	
3	GB/97.1-97	08-039-0803	Washer	
4	18102-058-0000	08-039-0804	Cover, Exhaust Pipe	
5	GB/T16674-96	08-039-0805	Bolt M6X12	
6	GB/T96-2000	08-039-0806	Washer	
7	18101-023-0000	08-039-0807	Gasket, Exhaust Pipe	
8	90304-058-0000	08-039-0808	Nut M8	
9	18150-058-0000	08-039-0809	Muffler Assy	
10	18160-058-0000	08-039-0810	Muffler	
11	18170-058-0000	08-039-0811	Spark Arresstor	
12	GB/T70.1-2000	08-039-0812	Screw M6X10	
13	18152-058-0000	08-039-0813	Protector 1	
14	18153-058-0000	08-039-0814	Protector 2	
15	GB/T818-2000	08-039-0815	Bolt M5X10	
16	GB/T97.1-85	08-039-0816	Nut M5	
17	18194-023-0000	08-039-0817	Clamp	
18	18107-058-0000	08-039-0818	Clamp, Exhaust Pipe	
19	18181-058-0000	08-039-0819	Damper	
20	18126-023-0000	08-039-0820	Clamp	
21	18106-058-0000	08-039-0821	Gasket, Muffler	
22	GB/T16674-96	08-039-0822	Bolt M8X25	
23	GB/T96-85	08-039-0823	Washer	
24	GB/T16674-96	08-039-0824	Bolt M8X40	
25	18127-058-0000	08-039-0825	Washer	
26	18108-058-0000	08-039-0826	Exhaust Hoop 2	
27	18109-058-0000	08-039-0827	Exhaust Hoop 1	

Fig. 09 Front Suspension




Ref	Code	Part Number	Description	Qty
1	56210-058-0000	08-039-0901	Front Left Upper A-Arm	
2	56202-058-0000	08-039-0902	Bushing	
3	56310-058-0000	08-039-0903	Front Right Upper A-Arm	
4	GB/T5783-96	08-039-0904	Bolt M6X12	
5	GB/T9457-1988	08-039-0905	Nut M10X1.25	
6	GB/T91-2000	08-039-0906	Cotter Pin	
7	56220-058-0000	08-039-0907	Front Left Lower A-Arm	
8	56620-058-0000	08-039-0908	Ball Joint, Left	
9	GB894.1-86	08-039-0909	Circlip	
10	90301-023-0000	08-039-0910	Nut M6	
11	56320-058-0000	08-039-0911	Front Right Lower A-Arm	
12	56620-058-0000	08-039-0912	Ball Joint, Right	
13	GB894.1-86	08-039-0913	Circlip	
14	56205-058-0000	08-039-0914	Washer	
15	GB/T16674-96	08-039-0915	Bolt M10X1.25X40	
16	GB/T6184-2000	08-039-0916	Nut M10X1.25	
17	GB/T894.1-86	08-039-0917	Washer	
18	GB/T16674-96	08-039-0918	Bolt M10X1.25X65	
19	GB/T6184-2000	08-039-0919	Nut M10X1.25	
20	55300-058-0000	08-039-0920	Front Shock	
21	GB/T16674-96	08-039-0921	Bolt M10X1.25X50	
22	GB/T6184-2000	08-039-0922	Nut M10X1.25	
23	83702-058-0000	08-039-0923	Protection Cover, Left	
24	83703-058-0000	08-039-0924	Protection Cover, Right	
25	56221-058-0000	08-039-0925	Front Left Lower A-Arm Assy	
26	56321-058-0000	08-039-0926	Front Right Lower A-Arm Assy	
27	56311-058-0000	08-039-0927	Front Right Upper A-Arm Assy	
28	56211-058-0000	08-039-0928	Front Left Upper A-Arm Assy	

Fig. 10 Rear Shock and Sway Bar




Ref	Code	Part Number	Description	Qty
1	55100-058-0000	08-039-1001	Rear Shock	
2	GB/T16674-96	08-039-1002	Bolt M10X1.25X50	
3	GB/T6187.2-2000	08-039-1003	Nut M10X1.25	
4	57800-058-0000	08-039-1004	Sway Bar Assy	
5	57820-058-0000	08-039-1005	Sway Bar Link, Right	
6	57810-058-0000	08-039-1006	Sway Bar Link, Left	
7	GB/T6187.2-2000	08-039-1007	Nut M10X1.25	
8	57802-058-0000	08-039-1008	Bushing, Sway Bar	
9	57803-058-0000	08-039-1009	Bracket, Sway Bar	
10	GB/T16674-96	08-039-1010	Bolt M8X12	
11	57803-058-0000	08-039-1011	Sway Bar	
12	57803-058-0000	08-039-1012	Bushing	

Fig. 11 Rear A-Arm




Ref	Code	Part Number	Description	Qty
1	57210-058-0000	08-039-1101	Rear Left Upper A-Arm	
2	56202-058-0000	08-039-1102	Bushing	
3	GB/T16674-96	08-039-1103	Bolt M10X1.25X65	
4	56205-058-0000	08-039-1104	Washer	
5	57310-058-0000	08-039-1105	Rear Right Upper A-Arm	
6	GB/T16674-96	08-039-1106	Bolt M10X65	
7	57220-058-0000	08-039-1107	Rear Left Lower A-Arm	
8	GB/T16674-96	08-039-1108	Bolt M10X65	
9	57320-058-0000	08-039-1109	Rear Right Lower A-Arm	
10	GB/T16674-96	08-039-1110	Bolt M10X65	
11	GB/T6184-2000	08-039-1111	Bolt M10X1.25	
12	57221-058-0000	08-039-1112	Guard, Left A-Arm	
13	GB/T16674-96	08-039-1113	Bolt M6X12	
14	57321-058-0000	08-039-1114	Guard, Right A-Arm	
15	GB/T16674-96	08-039-1115	Bolt M6X12	
16	57311-058-0000	08-039-1116	Rear Right Upper A-Arm Assy	
17	57211-058-0000	08-039-1117	Rear Left Upper A-Arm Assy	
18	57322-058-0000	08-039-1118	Rear Right Lower A-Arm Assy	
19	57223-058-0000	08-039-1119	Rear Left Lower A-Arm Assy	

Fig. 12 Front Wheel and Axle




Ref	Code	Part Number	Description	Qty
1	41100-058-0000	08-039-1201	Front Wheel and Tire Assy	
2	41160-023-0000	08-039-1202	Front Tire 25X8-12	
3	41104-023-0000	08-039-1203	Tire Valve	
4	90303-058-0000	08-039-1204	Lugnut	
5	26101-058-0000	08-039-1205	Cap, Hub	
6	26103-058-0000	08-039-1206	Nut M20X1.5	
7	56710-058-0000	08-039-1207	Steering Knuckle Assy, LFT FR	
8	41111-058-0000	08-039-1208	Hub	
9	27110-058-0000	08-039-1209	CV Half Shaft, LFT	
10	27130-058-0000	08-039-1210	CV Half Shaft, RGT	
11	56720-058-0000	08-039-1211	Steering Knuckle Assy, RGT FR	
12	56713-058-0000	08-039-1212	Bearing	
13	GB893.2-86	08-039-1213	Snap Ring	
14	26121-058-0000	08-039-1214	Clamp, Large CV Boot	
15	27119-058-0000	08-039-1215	Inner CV Boot	
16	26122-058-0000	08-039-1216	Clamp, Small CV Boot	
17	27115-058-0000	08-039-1217	Outer CV Boot	
18	41102-058-0000	08-039-1218	Front Wheel 12X6	
19	27111-058-0000	08-039-1219	Clip, Axle	
20	27131-058-0000	08-039-1220	Clip, CV	

Fig. 13 Front Differential




Ref	Code	Part Number	Description	Qty
1	27200-058-0000	08-039-1301	Front Differential Assy	
2	27201-058-0000	08-039-1302	Housing, FR Differential	
3	27202-058-0000	08-039-1303	Housing, FR Differential Bearing	
4	GB/T96-85	08-039-1304	Washer	
5	27205-058-0000	08-039-1305	Pinion	
6	27226-058-0000	08-039-1306	Coupling	
7	GB/T6177 2-2000	08-039-1307	Nut M14X1.5	
8	27216-058-0000	08-039-1308	O-Ring	
9	27218-058-0000	08-039-1309	Oil Seal 48X65X9	
10	27219-058-0000	08-039-1310	Oil Seal 24X38X8	
11	27213-058-0000	08-039-1311	Shim	
12	GB/T70.1-2000	08-039-1312	Bolt M8X20	
13	27250-058-0000	08-039-1313	Ring Gear	
14	GB/T70.1-2000	08-039-1314	Screw M8X25	
15	GB/T77-2000	08-039-1315	Screw M8X10	
16	GB/T16674-96	08-039-1316	Bolt M10X25	
17	GB/T8930.1-1986	08-039-1317	Circlip	
18	27273-058-0000	08-039-1318	Roll Pin	
19	31500-058-0000	08-039-1319	2WD/4WD Servo Motor	
20	27271-058-0000	08-039-1320	Clutch, Differential	
21	27274-058-0000	08-039-1321	Shaft	
22	27272-058-0000	08-039-1322	Shift Fork	
23	31501-058-0000	08-039-1323	O-Ring	
24	27217-058-0000	08-039-1324	O-Ring	
25	GB/T 276-1994	08-039-1325	Bearing 6007R 35X62X14	
26	GB/T 276-1994	08-039-1326	Bearing 6912 60X85X13	
27	GB/T 276-1994	08-039-1327	Bearing 16007 35X62X9	
28	GB/T290-94	08-039-1328	Roller Bearing HK15211215X21X12	
29	GB/T16674-96	08-039-1329	Drain Bolt M10X1.25X15	
30	45600-023-04-23	08-039-1330	Copper Gasket 10X1.5	
31	27275-058-0000	08-039-1331	Coupling	
32	27214-058-0000	08-039-1332	Shim	
33	GB/T16674-96	08-039-1333	Bolt M14X1.5X10	
34	27222-058-0000	08-039-1334	Copper Gasket 14.1X1.5	
35	27212-058-0000	08-039-1335	Vent Tube	
36	90401-058-0000	08-039-1336	Circlip	
37	27530-058-0000	08-039-1337	Front Drive Shaft	
38	27276-058-0000	08-039-1338	Spring, FR Drive Shaft	
39	27502-058-0000	08-039-1339	Seal, FR Drive Shaft	

Fig. 14 Rear Wheel and Axle




Ref	Code	Part Number	Description	Qty
1	41200-058-0000	08-039-1401	Rear Wheel and Tire Assy	
2	41260-023-0000	08-039-1402	Rear Tire AT25X10	
3	41104-023-0000	08-039-1403	Tire Valve	
4	41211-058-0000	08-039-1404	Hub	
5	26101-058-0000	08-039-1405	Cap, Hub	
6	90302-058-0000	08-039-1406	Lugnut	
7	26110-058-0000	08-039-1407	CV Half Shaft, LFT RR	
8	26103-058-0000	08-039-1408	Nut M20X1.5	
9	57700-058-0000	08-039-1409	Rear Knuckle	
10	26130-058-0000	08-039-1410	CV Half Shaft, RGT RR	
11	57711-058-0000	08-039-1411	Bearing, Rear Knuckle	
12	GB893.2-86	08-039-1412	Snap Ring	
13	26119-058-0000	08-039-1413	Clamp, Large CV Boot	
14	26121-058-0000	08-039-1414	CV Boot, Inner	
15	26122-058-0000	08-039-1415	Clamp, Small CV Boot	
16	26115-058-0000	08-039-1416	CV Boot, Outter	
17	41202-058-0000	08-039-1417	Rear Wheel 12X8	
18	GB/T6187.1-2000	08-039-1418	Nut M10X1.25	
19	57705-058-0000	08-039-1419	Cover, Thrust	
20	57703-058-0000	08-039-1420	Bushing	
21	JB/T940.1-1995	08-039-1421	Zerk, Grease	
22	57704-058-0000	08-039-1422	Spacer	
23	GB/T16674-2000	08-039-1423	Bolt M10X1.25X95	
24	26111-058-0000	08-039-1424	Clip	

Fig. 15 Final Drive and Drive Shaft




Ref	Code	Part Number	Description	Qty
1	26200-058-0000	08-039-1501	Final Drive Assy	
2	26201-058-0000	08-039-1502	Housing, Final Drive	
3	GB5801-94	08-039-1503	Bearing HK223013	
4	GB5801-94	08-039-1504	Bearing HK556720	
5	26205-058-0000	08-039-1505	Pinion	
6	26235-058-0000	08-039-1506	Bearing	
7	26539-058-0000	08-039-1507	Boss, Drive Shaft	
8	26218-058-0000	08-039-1508	Oil Seal	
9	GB/T 276-1994	08-039-1509	Bearing 6305 25X62X17	
10	26216-058-0000	08-039-1510	O-Ring	
11	26234-058-0000	08-039-1511	Washer	
12	GB/T6174-2000	08-039-1512	Nut M12X1.25	
13	26226-058-0000	08-039-1513	Housing, Pinion Bearing	
14	26213-058-0000	08-039-1514	Shim	
15	26214-058-0000	08-039-1515	Shim, Thrust	
16	36510-058-0000	08-039-1516	Speed Sensor	
17	26222-058-0000	08-039-1517	O-Ring	
18	GB/T9074.1-2002	08-039-1518	Bolt M8X35	
19	GB/T96-85	08-039-1519	Washer	
20	GB/T16674-2000	08-039-1520	Bolt M8X25	
21	GB/T96-85	08-039-1521	Washer	
22	26236-058-0000	08-039-1522	Breather	
23	26202-058-0000	08-039-1523	Housing, Bearing	
24	GB/T77-2000	08-039-1524	Screw M8X45	
25	GB/T96-85	08-039-1525	Copper Gasket 8X15X1	
26	GB/T6177.1-2000	08-039-1526	Nut M8	
27	GB/T16674-2000	08-039-1527	Bolt M8X12	
28	GB/T96-85	08-039-1528	Copper Gasket 15X8.2X1	
29	26219-058-0000	08-039-1529	Oil Seal	
30	GB/T 276-1994	08-039-1530	Bearing 16017 85X130X14	
31	26217-058-0000	08-039-1531	O-Ring	
32	26215-058-0000	08-039-1532	Shim	
33	GB/T16674-2000	08-039-1533	Bolt M10X1.25X25	
34	GB/T16674-96	08-039-1534	Drain Bolt	
35	GB/T96-85	08-039-1535	Copper Gasket14X1.5	
36	26508-058-0000	08-039-1536	Spring	
37	26501-058-0000	08-039-1537	Drive Shaft	
38	GB/T894.1-1986	08-039-1538	Circlip	
39	26504-058-0000	08-039-1539	Coupling	
40	GB/T894.1-1986	08-039-1540	Circlip	
41	26109-058-0000	08-039-1541	Clip	
42	26502-058-0000	08-039-1542	Dust Boot 1	
43	26503-058-0000	08-039-1543	Dust Boot 2	
44	26233-058-0000	08-039-1544	Hose, Breather	
45	26206-058-0000	08-039-1545	Ring Gear	

Fig. 16 Rear Master Cylinder




Ref	Code	Part Number	Description	Qty
1	44500-058-0000	08-039-1601	Rear Master Cylinder	
2	43920-058-0000	08-039-1602	Cable, Control	
3	43200-058-0000	08-039-1603	Cable, Rear Brake	
4	37601-058-0000	08-039-1604	Bracket, Brake Light Switch	
5	GB/T16674-96	08-039-1605	Bolt M6X12	
6	43506-058-0000	08-039-1606	Guard, Brake Control	
7	90101-058-0000	08-039-1607	Bolt M6X16-10X4	
8	44516-058-0000	08-039-1608	Bracket, Master Cylinder	
9	GB/T16674-96	08-039-1609	Bolt M6X12	
10	GB/T16674-96	08-039-1610	Bolt M8X25	
11	18125-058-0000	08-039-1611	Guard 2	
12	GB/T16674-96	08-039-1612	Bolt M6X12	
13	44519-058-0000	08-039-1613	Cap, Master Cylinder	
14	44517-058-0000	08-039-1614	Diaphragm, Master Cylinder	
15	44518-058-0000	08-039-1615	Bushing, Master Cylinder Cap	

Fig. 17 Rear Brake




Ref	Code	Part Number	Description	Qty
1	44502-058-0000	08-039-1701	Rear Brake Disc	
2	44515-058-0000	08-039-1702	Bolt M6X30, Disc Brake	
3	GB/T6177-2000	08-039-1703	Nut M6	
4	44600-058-0000	08-039-1704	Rear Brake Caliper	
5	GB/T16674-96	08-039-1705	Bolt M10X1.25X30	
6	44525-058-0000	08-039-1706	Clip, Rear Brake Pad	
7	44603-058-0000	08-039-1707	Rear Brake Pad Set	

Fig. 18 Crankcase Air Ducts




Ref	Code	Part Number	Description	Qty
1	21505-058-0000	08-039-1801	Clamp	
2	21502-058-0000	08-039-1802	Joint, Air Duct 1	
3	21540-058-0000	08-039-1803	Air Duct 1	
4	21506-058-0000	08-039-1804	Clamp	
5	21501-058-0000	08-039-1805	Joint, Air Duct 2	
6	21631-058-0000	08-039-1806	Grommet	
7	21520-058-0000	08-039-1807	Air Duct 2	
8	21523-058-0000	08-039-1808	Clip	
9	21521-058-0000	08-039-1809	Cover, Drain Pipe	

Fig. 19 Shifter




Ref	Code	Part Number	Description	Qty
1	23400-058-0000	08-039-1901	Shifter Assy	
2	23440-058-0000	08-039-1902	Shift Rod Joint	
3	GB/T6177-2000	08-039-1903	Nut M12	
4	23453-058-0000	08-039-1904	Shift Rod	
5	GB/T6177-2000	08-039-1905	Nut M12	
6	23460-058-0000	08-039-1906	Shift Guide Joint	
7	GB96-85	08-039-1907	Washer	
8	GB/T16674-2000	08-039-1908	Bolt	
9	90301-058-0000	08-039-1909	Plastic Screw	
10	23411-058-0000	08-039-1910	Shift Knob	
11	90402-058-0000	08-039-1911	Clip	
12	23417-058-0000	08-039-1912	Drain Tube	
13	23418-058-0000	08-039-1913	Plug, Drain Tube	
14	23441-058-0000	08-039-1914	Boot, Shift Joint	
15	23416-058-0000	08-039-1915	Clamp, Shift Boot	
16	23415-058-0000	08-039-1916	Shift Boot	
17	23410-058-0000	08-039-1917	Shifter	

Fig. 20 Tail Light




Ref	Code	Part Number	Description	Qty
1	35200-058-0000	08-039-2001	Tail Light Assy	
2	35202-058-0000	08-039-2002	Bulb 12V5W/21W	
3	35203-058-0000	08-039-2003	Housing, Tail Light	
4	GB/T845-85	08-039-2004	Screw 3.9X16	

Fig. 21 Fuel Tank




Ref	Code	Part Number	Description	Qty
1	81100-058-0000	08-039-2101	Fuel Tank	
2	36210-058-0000	08-039-2102	Fuel Sensor	
3	36201-058-0000	08-039-2103	Gasket, Fuel Sensor	
4	36202-058-0000	08-039-2104	Bracket, Fuel Sensor	
5	GB/T16674-96	08-039-2105	Bolt M5X16	
6	81300-058-0000	08-039-2106	Fuel Cap	
7	81400-058-0000	08-039-2107	Fuel Petcock	
8	81404-058-0000	08-039-2108	Cover, Fuel Switch Lever	
9	19611-058-0000	08-039-2109	Clip	
10	GB818-85	08-039-2110	Screw M5X12	
11	81407-023-0000	08-039-2111	Gasket, Fuel Petcock	
12	GB818-85	08-039-2112	Screw M5X12	
13	81401-058-0000	08-039-2113	Fuel Switch Lever	
14	GB818-85	08-039-2114	Screw M4X15	
15	81106-058-0000	08-039-2115	Grommet	
16	81103-058-0000	08-039-2116	Collar	
17	GB/T5783-2000	08-039-2117	Bolt M6X30	
18	81105-058-0000	08-039-2118	Grommet	
19	81102-058-0000	08-039-2119	Collar	
20	16501-058-0000	08-039-2120	Fuel Line	
21	36200-058-0000	08-039-2121	Fuel Sensor Assy	
22	16511-023-0000	08-039-2122	Breather Hose	
23	81108-058-0000	08-039-2123	Guard, Fuel Tank	

Fig. 22 Front Master Cylinder




Ref	Code	Part Number	Description	Qty
1	44100-058-0000	08-039-2201	Front Master Cylinder Assy	
2	44108-058-0000	08-039-2202	Clip, Brake Line	
3	GB/T16674-2000	08-039-2203	Bolt M6X12	
4	44109-058-0000	08-039-2204	Front Brake Switch	
5	GB/T16674-2000	08-039-2205	Bolt M5X25	
6	44117-058-0000	08-039-2206	Bracket, Front Master Cylinder	
7	44103-058-0000	08-039-2207	Front Master Cylinder	
8	44118-058-0000	08-039-2208	Bolt, Front Brake Lever	
9	44116-058-0000	08-039-2209	Lever, Front Brake	
10	GB/T6187.2-2000	08-039-2210	Nut M8	

Fig. 23 Front Brake




Ref	Code	Part Number	Description	Qty
1	44102-058-0000	08-039-2301	Front Brake Disc	
2	90102-023-0000	08-039-2302	Bolt M8X20, Front Brake Disc	
3	44104-058-0000	08-039-2303	Cover, Front Brake Disc	
4	GB/T16674-96	08-039-2304	Bolt M6X12	
5	GB/T16674-96	08-039-2305	Bolt M8X14	
6	44200-023-0000	08-039-2306	Left Front Brake Caliper	
7	44301-58-0000	08-039-2307	Right Front Brake Caliper	
8	44203-058-0000	08-039-2308	Front Brake Pad Set	

Fig. 24 Footrest




Ref	Code	Part Number	Description	Qty
1	54220-058-0000	08-039-2401	Support, Left Footrest	
2	54230-058-0000	08-039-2402	Support, Right Footrest	
3	GB/T16674-96	08-039-2403	Bolt M8X12	
4	GB/T6184-2000	08-039-2404	Nut M6	
5	GB97.1-85	08-039-2405	Washer	
6	GB/947-88	08-039-2406	Screw M6X16	
7	90102-058-0000	08-039-2407	Bolt M6X16-10X4	
8	43520-058-0000	08-039-2408	Bracket	
9	GB/T16674-96	08-039-2409	Bolt M8X25	
10	43512-058-0000	08-039-2410	Shaft, Rear Brake Pedal	
11	GB/T16674-2000	08-039-2411	Bolt M8X30	
12	GB/T96-85	08-039-2412	Washer	
13	43501-058-0000	08-039-2413	Rear Brake Pedal	
14	43511-058-0000	08-039-2414	Lever, Rear Brake Pedal	
15	43507-058-0000	08-039-2415	Clip	
16	GB97.1-85	08-039-2416	Washer	
17	GB/T955-87	08-039-2417	Washer, Wave	
18	43513-058-0000	08-039-2418	Return Spring 1, Rear Brake Pedal	
19	43504-058-0000	08-039-2419	Return Spring 2, Rear Brake Pedal	
20	82710-058-0000	08-039-2420	Left Footrest	
21	82720-058-0000	08-039-2421	Right Footrest	

Fig. 25 Instruments




Ref	Code	Part Number	Description	Qty
1	36100-058-0000	08-039-2501	Instrument Cluster	
2	GB/T6177-2000	08-039-2502	Nut M5	

Fig. 26 Seat




Ref	Code	Part Number	Description	Qty
1	71200-058-0000	08-039-2601	Seat	
2	71203-058-0000	08-039-2602	Bumper, Seat	

Fig. 27 Side Covers




Ref	Code	Part Number	Description	Qty
1	19301-058-0000	08-039-2701	Recovery Tank	
2	19302-058-0000	08-039-2702	Cap, Recovery Tank	
3	90102-058-0000	08-039-2703	Bolt M6X16-10X4	
4	19304-058-0000	08-039-2704	Vent Hose, Recovery Tank	
5	19303-058-0000	08-039-2705	Hose, Recovery Tank	
6	GB/T16674-2000	08-039-2706	Bolt M6X16	
7	19305-058-0000	08-039-2707	Clip	
8	83100-058-0000	08-039-2708	Cover, Fuel Tank	
9	81108-058-0000	08-039-2709	Heat Insulation, Fuel Tank Cover	
10	90302-058-0000	08-039-2710	Screw	
11	83102-058-0000	08-039-2711	Grommet	
12	90102-058-0000	08-039-2712	Bolt M6X16X10X4	
13	82402-058-0000	08-039-2713	Right Cover, Fuel Tank	
14	82401-058-0000	08-039-2714	Heat Insulation, Right Fuel Tank Cover	
15	82302-058-0000	08-039-2715	Left Cover, Fuel Tank	
16		08-039-2716	Heat Insulation, Left Fuel Tank Cover	
17	19540-058-0000	08-039-2717	Air Duct 3	

Fig. 28 Rack and Guard




Ref	Code	Part Number	Description	Qty
1	72802-058-0000	08-039-2801	Cover, Front Bumper	
2	GB/T818-2000	08-039-2802	Screw M6X16	
3	GB/T16674-96	08-039-2803	Bolt M8X12	
4	72810-058-0000	08-039-2804	Front Bumper	
5	72811-058-0000	08-039-2805	Cap, Front Bumper	
6	GB/T16674-2000	08-039-2806	Bolt M8X16	
7	72701-058-0000	08-039-2807	Cover, Rear Rack	
8	GB/T947-88	08-039-2808	Screw M5X16	
9	72501-058-0000	08-039-2809	Cover, Front Rack	
10	GB/T947-88	08-039-2810	Screw M5X16	
11	GB/T16674-2000	08-039-2811	Bolt M8X12	
12	72510-058-00000	08-039-2812	Front Rack	
13	72710-058-0000	08-039-2813	Rear Rack	

Fig. 29 Rear Cover




Ref	Code	Part Number	Description	Qty
1	82200-058-0000	08-039-2901	Rear Cover	
2	GB/T16674-96	08-039-2902	Bolt M6X12	
3	83204-058-0000	08-039-2903	Right Fender Flare, Rear Cover	
4	82220-058-0000	08-039-2904	Tail Light Panel	
5	82201-058-0000	08-039-2905	Lid, Rear Cover	
6	54260-058-0000	08-039-2906	Seat Bracket	
7	82304-058-0000	08-039-2907	Heat Insulation	
8	GB/T6174-2000	08-039-2908	Nut M6	
9	83203-058-0000	08-039-2909	Left Fender Flare, Rear Cover	
10	GB/T818-2000	08-039-2910	Screw M6X16	
11	GB/T818-2000	08-039-2911	Screw M6X20	
12	91214-023-0000	08-039-2912	Grommet	
13	GB/T97.1-85	08-039-2913	Washer	

Fig. 30 Front Cover




Ref	Code	Part Number	Description	Qty
1	82100-058-0000	08-039-3001	Front Cover	
2	GB/T818-2000	08-039-3002	Screw M6X16	
3	90102-058-0000	08-039-3003	Bolt M6X16-10X4	
4	GB/T16674-96	08-039-3004	Bolt M6X14	
5	82112-058-0000	08-039-3005	Panel, Front Cover	
6	91214-023-0000	08-039-3006	Grommet	
7	90302-058-0000	08-039-3007	Plastic Rivnut	
8	82500-058-0000	08-039-3008	Headlight Panel, Front Cover	
9	GB/T97.1-85	08-039-3009	Washer	
10	GB/T6174-2000	08-039-3010	Nut M6	
11	GB/T818-2000	08-039-3011	Screw M6X16	
12	83717-058-0000	08-039-3012	Protection Cover	
13	GB/T6174-2000	08-039-3013	Nut M6	
14	GB/T818-2000	08-039-3014	Washer	
15	82102-058-0000	08-039-3015	Cover, Panel	
16	82104-058-0000	08-039-3016	Instrument Panel	
17	90101-023-0000	08-039-3017	Bolt M6X16-10X16	
18	GB/T818-2000	08-039-3018	Screw M6X16	
19	83718-058-0000	08-039-3019	Seal	
20	GB/T818-2000	08-039-3020	Screw M6X20	
21	83201-058-0000	08-039-3021	Left Fender Flare, Front Cover	
22	83202-058-0000	08-039-3022	Right Fender Flare, Front Cover	
23	82131-058-0000	08-039-3023	Lid, Storage Bin	
24	82132-058-0000	08-039-3024	Retainer Ring, Storage Bin	
25	82130-058-0000	08-039-3025	Storage Bin	

Fig. 31 Headlight




Ref	Code	Part Number	Description	Qty
1	35110-058-0000	08-039-3101	Left Headlight Assy	
2	35112-058-0000	08-039-3102	Parking Light Bulb12v3W	
3	35113-058-0000	08-039-3103	N/A	
4	35114-058-0000	08-039-3104	Headlight bulb12v35W/35W	
5	GB/T845-85	08-039-3105	Screw 3.9X13	
6	35120-058-0000	08-039-3106	Right Headlight Assy	

Fig. 32 Tail Light 2



Ref	Code	Part Number	Description	Qty
1	35501-058-0000	08-039-3201	Lens, Tail Light 2	
2	35502-058-0000	08-039-3202	Bulb12V10W	
3	35503-058-0000	08-039-3203	Housing, Tail Light 2	
4	35500-058-0000	08-039-3204	Tail Light 2 Assy	
5	GB/T845-85	08-039-3205	Screw3.9X13	
6	35600-058-0000	08-039-3206	Tail Light 2 Assy	

Fig. 33 Emblem 1




Ref	Code	Part Number	Description	Qty
1	92111-058-0000	08-039-3301	Warning Plate-1	
2	92112-058-0000	08-039-3302	Warning Plate-2	
3	92113-058-0000	08-039-3303	Warning Plate-3	
4	92114-058-0000	08-039-3304	Warning Plate-4	
5	GB12618-90	08-039-3305	Rivet	
6	GB97.1-85	08-039-3306	Washer	
7	34801-023-0000	08-039-3307	Rear Reflector	

Fig. 34 Emblem 2



Ref	Code	Part Number	Description	Qty
1		08-039-3401	700cc	
2		08-039-3402	Discovery	
3		08-039-3403	Diamo	
4		08-039-3404	4X4	

Fig. 35 Evap Kit



Ref	Code	Part Number	Description	Qty
1	18500-025-0000	08-043-3201	Air Valve	
2	18503-055-0000	08-043-3202	Clamp	
3	18505-055-0000	08-043-3203	Air Hose 1	
4	GB/T5787-1986	08-043-3204	Bolt M6X16	
5	18506-055-0000	08-043-3205	Clamp	
6	18507-055-0000	08-043-3206	Air Hose 2	
7	18501-025-0000	08-043-3207	Air Hose 3	
8	18502-025-0000	08-043-3208	Clamp	
9	18504-055-0000	08-043-3209	Evap Air Filter	

Fig. 36 Brake System Assembly

Ref	Code	Part Number	Description	Qty
1	44300-058-0000	08-039-3601	Complete Brake System Assy	




Fig. 37 Lock Set



1

Ref	Code	Part Number	Description	Qty
1	37201-058-0000	08-039-3701	Lock Set	